CDX-5270/5272

SERVICE MANUAL

US Model
Canadian Model
AEP Model
E Model
CDX-5270
German Model
CDX-5272

Photo: CDX-5270 US model

COMPACT disc DIGITAL AUDIO

Model Name Using Similar Mechanism	CDX-5260/5262
CD Drive Mechanism Type	MG-205X-130

SPECIFICATIONS

Power amplifier section

Outputs	Speaker outputs (sure seal connectors)
Speaker impedance	4 – 8 ohms
Maximum power output	30 W × 4 ch (at 4 ohms)

CD player section

System	Compact disc digital audio system
Frequency response	10 – 20,000 Hz
Wow and flutter	Below the measurable limit
Signal-to-noise ratio	90 dB

Tuner section

FM

Tuning range	87.5 – 107.9 MHz (at 200 kHz step) (US, Canadian Model) 87.5 – 108.0 MHz (at 50 kHz step) (AEP, E, German Model)
Antenna terminal	External antenna connector
Intermediate frequency	10.7 MHz
Sensitivity	8 dBf
Selectivity	75 dB at 400 kHz
Signal-to-noise ratio	65 dB (stereo), 70 dB (mono)
Harmonic distortion at 1 kHz	0.5% (stereo), 0.3% (mono)
Separation	35 dB
Frequency response	30 – 15,000 Hz

MW

Tuning range	530 – 1,710 kHz (at 10 kHz atep) (US, Canadian Model) 530 – 1,620 kHz (at 10 kHz step) (E Model) 531 – 1,602 kHz (at 9 kHz step) (AEP, E, German Model)
Antenna terminal	External antenna connector
Intermediate frequency	10.71 MHz/450 kHz
Sensitivity	30 µV
Signal-to-noise ratio	55 dB
Harmonic distortion at 1 kHz	0.3%

LW (CDX-5270: AEP Model)

Tuning range	153 – 281 kHz
Antenna terminal	External antenna connector
Intermediate frequency	10.71 MHz/450 kHz
Sensitivity	50 µV
Signal-to-noise ratio	55 dB
Harmonic distortion at 1 kHz	0.3%

— continued on next page —

使用時に添付資料も参照のこと
Refer to the additional documents.

CDX-5270
FM/MW/LW COMPACT DISC PLAYER
CDX-5272
FM/MW/SW COMPACT DISC PLAYER

SONY®

SW (CDX-5272: German Model)

Tuning range	5,950 – 6,205 kHz
Antenna terminal	External antenna connector
Intermediate frequency	10.71 MHz/450 kHz
Sensitivity	50 μV
Signal-to-noise ratio	55 dB
Harmonic distortion at 1 kHz	0.3%

General

Tone controls	Bass ± 8 dB at 100 Hz Treble ± 8 dB at 10 kHz
Power requirements	12 V DC car battery (negative ground)
Current drain	1 A (CD play) 1.5 A (during disc loading or eject)
Operating temperature	–10°C to 50°C
Dimensions	Approx. 186 × 57 × 172 mm (w/h/d) not incl. projecting parts and controls
Mass	Approx. 1.5 kg
Supplied accessories	Mounting hardware (1 set) Power connecting cord (1) Front panel case (1)

Design and specifications subject to change without notice.

TABLE OF CONTENTS

Section	*Title*	*Page*
Specifications		1
Servicing Notes		2
1.	**GENERAL**	
	Location and Function of Controls	3
	Connection	6
2.	**DISASSEMBLY**	8
3.	**TEST MODE**	9
4.	**ELECTRICAL ADJUSTMENTS**	
	CD Section	12
	Tuner Section	12
5.	**DIAGRAMS**	
5-1.	IC Pin Description	14
5-2.	Block Diagram	17
5-3.	Printed Wiring Boards – Mechanism Deck Section –	20
5-4.	Schematic Diagram – Mechanism Deck Section –	23
5-5.	Schematic Diagram – Main Section –	28
5-6.	Printed Wiring Board – Main Section –	33
5-7.	Printed Wiring Board – Display Section –	36
5-8.	Schematic Diagram – Display Section –	39
6.	**EXPLODED VIEWS**	42
7.	**ELECTRICAL PARTS LIST**	46

SERVICING NOTES

Laser Diode Properties

- Material: GaAlAs
- Wavelength: 780 nm
- Emission Duration: continuous
- Laser Output Power: less than 44.6 μW*

  * This output is the value measured at a distance of 200 mm from the objective lens surface on the Optical Pick-up Block.

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body.
During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.
The flexible board is easily damaged and should be handled with care.

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK ⚠ OR DOTTED LINE WITH MARK ⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE ⚠ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

Location and Function of Controls

Main Unit





Refer to the pages in ● for details.

1 **OFF button**
Press to turn off the unit.

2 **Reset button (located on the front side of the unit hidden by the front panel)**
Press this button when you use this unit for the first time, when you have changed the car battery, or when the buttons of this unit do not function. Note that when the button is pressed, the memories on the preset number buttons will be erased.

3 **Disc Insertion slot**

4 **CD (disc play) button** ⑭

5 **⏏ (eject) button** ⑭

6 **RELEASE (front panel release) button** ⑪

7 **Receptor (for the wireless remmote commander)** (CDX-5270/5272)
MUTE button (CDX-5070/5072)
Press to mute the sound momentarily. Press again to restore the previous volume level. This button will also be canceled in the following cases:
— when the [+] or OFF button is pressed
— when the ignition key of your car has been turned to the OFF position for more than ten seconds.

8 **MUTE button** (CDX-5270/5272)
LOUD (loudness) button (CDX-5070/5072)
Press to reinforce the bass and treble especially when listening at a low volume level. To cancel the mode, press it again.

9 **Display window**

10 **BTM (best tuning memory) button** ⑯

11 **FM (radio on/band select) button** (CDX-5070/5270) ⑮
At each pressing, the button changes the band cyclically as follows:
FM1→ FM2→ FM3

SDK (traffic announcement) button (CDX-5072/5272) ⑱

12 **MW/LW (radio on/band select) button** (CDX-5070/5270) ⑮
At each pressing, the button changes the band as follows:
MW ⟷ LW

TUNER (radio on/band select) button (CDX-5072/5272) ⑮
At each pressing, the button changes the band cyclically as follows:
FM1→ FM2→ FM3→ MW→ SW→ FM1

13 **SENS (sensitivity) button** (CDX-5070/5072) ⑬
SENS (sensitivity/loudness) button (CDX-5270/5272) ⑬
Press for more than two seconds to reinforce the bass and treble especially when listening at a low volume level. To disengage the button, press it again for more than two seconds. (Loudness function).



14 [-] [+] (volume/bass/treble/balance/fader control) buttons
Press to adjust each mode.

15 SEL (control mode select) button
Press to select the desired control mode: BAS (bass), TRE (treble), BAL (balance), FAD (fader) or VOL (volume).

16 DSPL (display change/time set) button ⓬
At each pressing, the button changes the display modes as follows:

During CD play	During radio reception
Elapsed playing time/track number ⟷ Clock	Frequency ⟷ Clock

Display window	Control mode	Press [-]	Press [+]
BAS	Bass control	For less bass	For more bass
TRE	Treble control	For less treble	For more treble
BAL	Balance control	To decrease the right-speakers' volume	To decrease the left-speakers' volume
FAD	Fader control	To decrease the rear-speakers' volume	To decrease the front-speakers' volume
VOL	Volume control	For less volume	For more volume

These [-] [+] buttons normally function as the volume control. Adjust the level within three seconds after selecting the desired control mode with the SEL button. Otherwise, the mode will go back to the volume control mode.



		During CD play	During radio reception
17	**AMS/SEEK button** [⏮ AMS/SEEK ⏭]	**AMS (Automatic Music Sensor) function** ⏮: Press once to locate the beginning of the track being played. ⏭: Press once to locate the beginning of the next track. Press repeatedly to locate previous or succeeding tracks.	**Automatic tuning ⓯**
18	**MANU button** [◀◀ MANU ▶▶]	**Manual search** ◀◀: Keep pressed to go back at high speed. ▶▶: Keep pressed to go ahead at high speed.	**Manual tuning ⓯**
19	**INTRO button** [INTRO 1]	**Intro scan ⓮**	**Preset number buttons ⓱**
20	**REPEAT button** [REPEAT 2]	**Repeat play ⓮**	
21	**SHUF button** [SHUF 3]	**Shuffle play ⓮**	
22	[4] [5] [6]	–	

23 POWER SELECT switch (located on the bottom of the unit)
See "POWER SELECT Switch" in the installation/connections manual.

Changing the illumination color (CDX-5270/5272)

Press the [INTRO 1] button while pressing the SEL button.

Muting the beep tone

Press the [6] button while pressing the SEL button. To obtain the beep tone again, press these buttons once more.

Location and Function of Controls

Optional Wireless Remote Commander RM-X40 (CDX-5270/5272)



Buttons of the same function as those on the main unit

1 **OFF button**

	During CD play	During radio reception
4	AMS (Automatic Music Sensor) button	SEEK (automatic tuning) button ⓯

6 **MUTE button**

7 **(volume/bass/treble/balance/fader control) buttons** ❽
Press to adjust each mode.

8 **DSPL (display change) button** ❽ ⓬

9 **SEL (control mode select) button** ❽
Press to select the desired control mode.

Different function buttons

2 **MODE button**

During CD play	During radio reception
No function	At each pressing, the button changes the band.

3 **SOURCE button**
At each pressing, the button changes the source as follows: RADIO ⟷ CD

	During CD play	During radio reception
5	No function	**PRESET (preset search) button.** Receives the stations memorized on the preset number buttons. (Preset search function)

When the POWER SELECT switch is set to the OFF position, the unit cannot be operated with the wireless remote commander unless one of the CD, FM, MW/LW (CDX-5070/5270) and TUNER (CDX-5072/5272) buttons of the unit is pressed or a disc is inserted to activate the unit first.

Connections / Connexions / Anschluß / Collegamenti

Caution

- This unit is designed for negative ground 12 V DC operation only.
- Before making connections, disconnect the ground terminal of the car battery to avoid short circuits.
- Connect the **yellow** and **red** power input leads only after all other leads have been connected.
- Be sure to connect the red power input lead to the positive 12 V power terminal which is energized when the ignition key is in the accessory position.
- **Run all ground wires to a common ground point.**

When the Unit is Used in a Car with No Accessory Position on the Ignition Key

— POWER SELECT Switch

The illumination on the front panel is factory-set to be turned on even when the unit is not being played. However, this setting may cause some car battery wear if **the unit is used in a car with no accessory position on the ignition key.** To avoid this battery wear when using the unit in such a car, **set the POWER SELECT switch located on the bottom of the unit to the OFF position, then press the reset button.** The illumination is reset to stay off while the unit is not being played.

Note

The caution alarm for the front panel is not activated when the POWER SELECT switch is set to the OFF position.

Précautions

- Cet appareil est conçu pour fonctionner sur courant continu de 12 V avec masse négative.
- Avant d'effectuer les connexions, débrancher la borne de terre de la batterie du véhicule pour éviter tout court-circuit.
- Branchez les fils d'entrée d'alimentation **jaune** et **rouge** seulement après avoir terminé tous les autres branchements.
- Veillez à ne pas raccorder le fil rouge d'entrée d'alimentation à la borne positive de 12 V qui est alimentée quand la clé de contact est sur la position accessoire.
- **Rassembler tous les fils de terre en un point de masse commun.**

Si l'appareil est utilisé dans une voiture dont la clé de contact n'a pas de position accessoire

— Interrupteur POWER SELECT

L'éclairage du panneau avant est réglé en usine de manière à s'allumer même quand l'appareil ne fonctionne pas. Cependant, ce réglage risque d'épuiser la batterie **si l'appareil est utilisé dans une voiture dont la clé de contact ne possède pas de position accessoire.** Pour éviter d'épuiser la batterie, régler l'interrupteur **POWER sur le socle de l'appareil sur OFF, puis appuyer sur la touche de réinitialisation.** L'éclairage est réglé pour rester éteint quand l'appareil n'est pas utilisé.

Remarque

Quand l'interrupteur POWER SELECT est réglé sur OFF, l'avertisseur du panneau avant ne fonctionne pas.

Vorsicht

- Dieses Gerät ist ausschließlich fur eine negativ geerdete 12-V-Autobatterie bestimmt.
- Trennen Sie vor dem Anschließen des Geräts die Erdungsklemme der Batterie ab, um einen Kurzschluß zu vermeiden.
- Schließen Sie das **gelbe** und **rote** Stromversorgungskabel erst an, wenn alle anderen Kabel bereits angeschlossen sind.
- Leiten Sie das rote Stromversorgungskabel an einen positiven 12-V-Kontakt des Bordnetzes, der in der Zubehörposition des Zündschlosses unter Strom steht.
- **Leiten Sie alle Erdungskabel an einen gemeinsamen Massepunkt ab.**

Wenn das Zündschloß Ihres Wagens keine Zubehörposition besitzt

— POWER SELECT-Schalter

Das Gerät ist werksseitig so voreingestellt, daß das Bedienungspult auch dann beleuchtet ist, wenn das Gerät nicht betrieben wird. Besitzt das Zündschloß Ihres Fahrzeugs keine **Zubehörposition, so ist die Beleuchtung ständig eingeschaltet** und entzieht der Batterie Strom. Stellen Sie in einem solchen Fall den **POWER SELECT-Schalter an der Unterseite des Geräts auf OFF, und drücken Sie dann die Rückstelltaste.** Bei ausgeschaltetem Gerät ist das Bedienungspult dann nicht mehr beleuchtet.

Hinweis

Der Warnton ertönt nicht, wenn der POWER SELECT-Schalter auf OFF gestellt ist.

Attenzione

- Questo apparecchio è stato progettato per l'uso solo in funzionamento a 12 V CC con massa negativa.
- Prima di eseguire i collegamenti, scollegare il terminale di massa della batteria dell'auto per evitare cortocircuiti.
- Collegare i cavi di collegamento alimentazione **rosso e giallo** solo dopo aver collegato tutti gli altri cavi.
- Assicurarsi di collegare il cavo rosso di collegamento alimentazione al terminale di alimentazione 12 V positivo che è sotto tensione quando la chiavetta di accensione è in posizione accessoria.
- **Portare tutti i cavi di massa a un punto di massa comune.**

Quando si usa l'apparecchio in un'auto priva di posizione accessoria per la chiavetta di accensione

— Interruttore POWER SELECT

L'illuminazione del pannello anteriore è stata predisposta in fabbrica per l'attivazione anche quando non si usa l'apparecchio. Tuttavia questa regolazione può causare scaricamento della batteria dell'auto **se si usa l'apparecchio in un'auto priva di posizione accessoria per la chiavetta di accensione.** Per evitare lo scaricamento della batteria quando si usa l'apparecchio in questo tipo di auto, **regolare su OFF l'interruttore POWER SELECT situato sul fondo e quindi premere il puisante di azzeramento.** L'illuminazione viene così regolata per lo spegnimento quando non si usa l'apparecchio.

Nota

La suoneria di avvertimento per il pannello anteriore non si attiva quando l'interruttore POWER SELECT è regolato sulla posizione OFF.


Change the position with a jeweler's screwdriver, etc.
Changer la position avec un tournevis de joaillier ou un objet similaire.
Den Schalter mit einem kleinen Schraubenzieher o.ä. umstellen.
Cambiare la posizione con un cacciavite da gioielliere, ecc.

Connection Diagram / Schémas de connexion / Anschlußdiagramm / Schema di collegamento

Example 1
Exemple 1
Beispiel 1
Esempio 1



Example 2
Exemple 2
Beispiel 2
Esempio 2



Example 3 (CDX-5270/5272)
Exemple 3
Beispiel 3
Esempio 3



Connections of Example / Connexions de l'exemple / Anschlußbeispiel / Collegamenti per l'esempio



Notes on the control leads
- The power antenna control lead (blue) supplies +12 V DC when you turn on the tuner.
- A power antenna without relay box cannot be used with this unit.

Memory hold connection
When the yellow power input lead is connected, power will always be supplied to the memory circuit even when the ignition key is turned off.

Remarques sur les fils de contrôle
- Le fil de contrôle de l'antenne électrique (bleu) fournit un courant continu de +12 V quand le tuner est allumé.
- Une antenne électrique sans boîtier de relais ne peut pas être utilisée avec cet appareil.

Connexion pour la conservation de la memoire
Lorsque le fil d'entrée d'alimentation jaune est connecté, le circuit de la memoire est alimenté en permanence même si la clé de contact est sur la position d'arrêt.

Hinweise zu den Steuerleitungen
- Die Motorantennen-Steuerleitung (blau) liegt auf +12 V Gleichspannung, wenn der Tuner eingeschaltet wird.
- Eine Motorantenne ohne Relaisbox kann nicht verwendet werden.

Zur Stromversorgung des Speichers
Wenn das gelbe Stromversorgungskabel angeschlossen ist, wird der Speicher stets (auch bei ausgeschaltetem Zündschloß) mit Strom versorgt.

Note sui cavi di controllo
- Il cavo di controllo dell'antenna automatica (blu) fornisce +12 V CC quando si accende il sintonizzatore.
- Non è possibile usare un'antenna automatica senza la scatola a relè con questo apparecchio.

Collegamento per la conservazione della memoria
Quando il cavo di ingresso alimentazione giallo è collegato, viene sempre fornita alimentazione al circuito di memoria anche quando la chiavetta di accensione è spenta.

Reset Button

When the installation and connections are over, be sure to press the reset button with a ball-point pen etc.

Touche de réinitialisation

Quand l'installation et les connexions sont terminees, appuyer sur la touche de reinitialisation avec un stylo bille ou un objet pointu.

Rückstelltaste

Nach der Installation und dem Anschluß muß die Rückstelltaste mit einem Kugelschreiber o.ä. gedrückt werden.

Pulsante di azzeramento

Dopo avere terminato l'installazione e i collegamenti, assicurarsi di premere il pulsante di azzeramento con la punta di una penna a sfera ecc.



SECTION 2
DISASSEMBLY

Note: Follow the disassembly procedure in the numerical order given.





SECTION 3
TEST MODE

Setting:

Method 1

Press keys in order of [4] → [5] → [1] for 2sec. under OFF condition.

Method 2

Pin㉗of IC501 (SYSTEM CONTROL) →Connected to GND →[RESET] button (S801)

Note: While the TEST MODE is set, the following will be displayed on the LCD.
Bit display "SHUF".

Releasing:

Press [OFF] key, or press [RESET] button (Open pin㉗ of IC501).

LCD display test

All segments of the display are lit up at the beginning of test mode.

Electronic volume test

[+] key :



[−] key : normal operation

[SEL] key :



[MUTE] key :



CD SECTION

Audio Measurement Mode

When CD is played, the AUDIO MEASUREMENT MODE turns on.

When "YEDS-18" is played in the measuring mode, only the following Track No. will be played. (BANK function)

Each time the [4] key is pressed, the measuring mode turns on/off cyclically.

Note: AUDIO MEASUREMENT MODE PLAY Track No.
No. 2, 3, 6, 7, 8, 10, 12, 13, 17
(These have been set assuming that YEDS-18 will be used.)

When YEDS-18 is used, the recording signals of the above tracks are as follows.

TNO	CONTENTS	EMPHASIS	PURROSE
2	1kHz Sine Wave 0dB L & R	OFF	Reference
3	20kHz Sine Wave 0dB L & R	OFF	Frequency
6	20kHz Sine Wave 0dB L & R	OFF	Modulation Noise
7	Infinity Zero −∞dB L & R	OFF	S/N
8	1kHz Sine Wave 0dB L	OFF	Channel Separation
10	1kHz Sine Wave 0dB R		
12	5kHz Sine Wave − 4.53dB L & R	ON	De emphasis
13	16kHz Sine Wave − 9.04dB L & R		
17	1kHz Sine Wave − 60dB L & R	OFF	Dynamic Range

Adjusting and Checking Functions

a) TRACKING OFFSET adjustment

Each time the [INTRO] key is pressed while the CD is played, the TRACKING SERVO turns on/off. The bit display "INTRO" on the LCD will be lit while the TRACKING SERVO is off.



Adjustment Location and Measurement point:

【MD BOARD】(SIDE B)



Proccdure:

Adjust RV1 so that the peak values of waveforms A and B become equal.

b) Focus search retry mode
Each time the [REPEAT] key is pressed while the CD is played, the FOCUS SEARCH RETRY MODE turns on/off.
When the FOCUS does not turn on in the FOCUS SEARCH RETRY MODE, the FOCUS search is repeated. Once the FOCUS turns on, the unit sets into the PLAY condition.
During the FOCUS SEARCH RETRY MODE, the "REP" bit display on the LCD will be lit.

Note: This mode is for checking the unit when FOCUS cannot be set.

CD Error Display

During CD PLAY in the TEST MODE, the following ERROR displays will be shown when CD errors occur.
"E- n1 n2"
n1 to n2 are determined by ERROR symptoms as shown below.

n1	n2
1 : SERVO ERROR	1 : FOCUS ERROR 2 : GFS ERROR 3 : SLED MAX TIME OVER 4 : SLED OVERRUN 5 : TOC READ ERROR
3 : LOADING /EJECT ERROR	1 : MAX TIME OVER (When sensor is passed during loading.) 2 : Loading of only 8cm CD, adaptor, etc. 3 : MAX TIME OVER (Until chucking ends during loading.) 4 : MAX TIME OVER (Until EJECT ends during ejecting.)
4 : TRACK JUMP	1 : FOCUS DOWN 2 : TRACK JUMP 3 : HANG UP
D : TEMP (HOT)	0
F : MD GIVE UP	7 : EJT

TUNER SECTION

When the tuner is turned on in the TEST MODE, all bands will first be set to f_{center}.

SEEK STOP TEST Function

a) When the [SEEK +] key is pressed, the unit is set to a frequency − 10 steps from the f_{center} and automatically seeks up to the f_{center}.
- If the unit seek stops at the f_{center} :
  The unit sets into the f_{center} reception state. Preset No. "1" will be displayed.
- If the unit seeks up to the f_{center} and cannot seek stop :
  It returns to the − 10 step frequency and seeks up again.
- If the unit seek stops before the f_{center} :
  The unit receives that frequency. Preset No. "3" will be displayed.

b) When the [SEEK −] key is pressed, the unit is set to a frequency + 10 steps from the f_{center} and automatically seeks down to the f_{center}.
Hereafter the same as the [SEEK +] key.

c) When the [MANU +] key is pressed, the unit is set to a frequency − 10 steps from the f_{max} and seeks up.
Hereafter the same as a) except that f_{center} is replaced by f_{max}.

d) Press the [MANU −] key to carry out normal MANUAL search down operations.

BAND SELECT

During TEST MODE, only the single band can be selected.

AGC CUT Function

In the AM ON condition, this function activates the $\overline{SEEK}$ port (IC603) and cuts AGC.
In the AGC CUT condition, the following displays on the LCD will light up.
Bit display "BANK"

When the [BTM] key is pressed for more than two seconds, AGC CUT turns on/off cyclically.
(The BTM function is unavailable.)

Note: Set the AGC CUT condition when adjusting the AM SEEK STOP sensitivity.
If the band changes from FM to AM, be sure to turn on the AGC CUT.

SD Signal Display
(For adjusting SEEK STOP LEVEL)

If the SD signal becomes high while a certain frequency is being received, after BAND displays such as "FM", "AM", etc. are shown, the following displays will light up.

"3" display

When the SD signal is low, nothing will be shown after the BAND is displayed.

BTM Signal Level Display Function
(For adjusting FM S meter)

When the [M.SCAN] key is pressed, the level of the S meter voltage of the A/D conversion input will be displayed. (Displayed at frequency display)

* Input FM f_{center} 35 dBμ at SG, and adjust the BTM signal level displayed to 0.6.

Press MANU +/−, etc. to return the frequency display. M.SCAN operations are unavailable.

DESTINATION	BAND	fmin	fcenter	fmax	step(SEEK)	step(MANUAL)
US, CND	FM	87.5MHz	97.9MHz	107.9MHz	200kHz	200kHz
	AM	530kHz	1,000kHz	1,710kHz	10kHz	10kHz
AEP, G	FM	87.50MHz	98.00MHz	108.00MHz	50kHz	50kHz
	MW	531kHz	999kHz	1,602kHz	9kHz	9kHz
	LW(AEP)	153kHz	216kHz	281kHz	9kHz	1kHz
	SW(G)	5,950kHz	6,080kHz	6,205kHz	5kHz	1kHz
E (9kHz step)	FM	87.50MHz	98.00MHz	108.00MHz	50kHz	50kHz
	AM	531kHz	999kHz	1,602kHz	9kHz	9kHz
E (10kHz step)	FM	87.50MHz	98.00MHz	108.00MHz	50kHz	50kHz
	AM	530kHz	1,000kHz	1,620kHz	10kHz	10kHz

Abbreviation CND : Canadian
G : German

SECTION 4
ELECTRICAL ADJUSTMENTS

CD SECTION

Focus Offset Adjustment

Adjustment Location and Measurement point:

[MD BOARD] (SIDE B)





Procedure:

1. Connect the oscilloscope to test point RF on the MD board.
2. Load a disc and set mode to PLAY.
3. Adjust RV2 so that the waveform on the oscilloscope (eye pattern) is maximum with good shape. "Well-shaped eye pattern" means that the mark "◇" is clearly distinguished at the center of the waveform.

Tracking Offset Adjustment

Refer to the "TEST MODE CD SECTION".

TUNER SECTION

FM Seek Stop Level Adjustment (FM SD Adjustment)

Setting:

Band : FM
Frequency : 97.9MHz (US, Canadian Model)
98MHz (E, AEP, German Model)



Carrier frequency : 97.9MHz (US, Canadian Model)
98MHz (E, AEP, German Model)
Modulation : 1kHz, 75kHz
Output level : 22dB (12.6 µ V)

AM Seek Stop Level Adjustment (AM SD Adjustment)

Setting:

Band : AM (MW)
Frequency : 1000kHz (US ,Canadian Model)
999kHz (E, AEP, German Model)



Carrier frequency : 1000kHz (US, Canadian Model)
999kHz (E, AEP, German Model)
Modulation : 400Hz 30 %
Output level : 32dB (40 µ V)

Procedure:

1. Set the "SD Signal Display" MODE of the TEST MODE.
2. Adjust RV3 (FM), RV1 (AM) of the TUNER UNIT, and erase the SD display "3" once.
3. Adjust RV3 (FM), RV1 (AM) so that a SD display lights up again.
4. Check with the "SEEK STOP TEST" function of the TEST MODE.

FM Stereo Separation Adjustment

Setting:

BAND : FM Stereo
Frequency : 97.9MHz (US, Canadian Model)
98MHz (E, AEP, German Model)



Carrier frequency : 97.9MHz (US, Canadian Model)
98MHz (E, AEP, German Model)
Modulation : Main channel : 1kHz, 33.75kHz deviation (45 %)
Pilot signal : 18kHz, 7.5kHz deviation (10 %)
Sub channel : 1kHz, 33.75kHz deviation (45 %)
Output level : 1mV (More than 35dB)

Procedure:

FM stereo signal generator output channel	VTVM connection	VTVM reading (dB)
L-CH	L-CH	ⓐ
R-CH	L-CH	ⓑ Adjust RV4 for minimum reading.
R-CH	R-CH	ⓒ
L-CH	R-CH	ⓓ Adjust RV4 for minimum reading.

Note: The separation values in the two channels should be identical.
ⓐ−ⓑ=ⓒ−ⓓ

Adjustment Location:

【MAIN BOARD】 (SIDE A)



ARI Level Adjustment (CDX-5272 only)

Setting:

Band switch : FM
Frequency: 98.0 MHz



Carrier frequency: 98.0 MHz
Output level: 60 dB μ V (1 mV)
Modulation: main; 1 kHz, 33.75 kHz deviation
sub; 1 kHz, 33.75 kHz deviation
19 kHz pilot; 7.5 kHz deviation
SK, BK, DK modulation

Procedure:

1. Adjust LV650 and RV601 so that the output become the maximum.

Specification: 1 Vrms or more

Adjustment Location:

【MAIN BOARD】 (SIDE A)



SECTION 5
DIAGRAMS

5-1. IC PIN DESCRIPTION

• IC501 SYSTEM CONTROL (μPD75518GF-166-3B9)

<table>
<tr><th>Pin No.</th><th>Pin Name</th><th>I / O</th><th>Description</th></tr>
<tr><td>1</td><td>KI0</td><td>I</td><td>Key input pin. (A/D conversion input.)</td></tr>
<tr><td>2</td><td>VREF</td><td>I</td><td>Reference voltage input pin of A/D conversion pins.</td></tr>
<tr><td>3</td><td>VDD</td><td>I</td><td rowspan="2">Power supply input. (5V)</td></tr>
<tr><td>4</td><td>VDD</td><td>I</td></tr>
<tr><td>5</td><td>CD DATA</td><td>O</td><td>SERIAL DATA output pin for the CD servo IC.</td></tr>
<tr><td>6</td><td>CD CLK</td><td>O</td><td>SERIAL CLOCK output pin for the CD servo IC.</td></tr>
<tr><td>7</td><td>CD LATCH</td><td>O</td><td>SERIAL DATA LATCH output pin for the CD servo IC.</td></tr>
<tr><td>8</td><td>CD RST</td><td>O</td><td>CD servo IC resetting output pin.</td></tr>
<tr><td>9</td><td>CD ON</td><td>O</td><td>Power supply ON/OFF control output pin. (CD servo IC)</td></tr>
<tr><td>10</td><td>MD ON</td><td>O</td><td>Power supply ON/OFF control output pin. (Mechanism deck section)</td></tr>
<tr><td>11</td><td>LM –</td><td rowspan="2">O</td><td rowspan="2">Loading motor control output pins.
<table>
<tr><th></th><th>LM –</th><th>LM +</th></tr>
<tr><td>FWD (Loading)</td><td>L</td><td>H</td></tr>
<tr><td>REV (Eject)</td><td>H</td><td>L</td></tr>
</table></td></tr>
<tr><td>12</td><td>LM +</td></tr>
<tr><td>13</td><td>N.C</td><td>–</td><td rowspan="2">Not used.</td></tr>
<tr><td>14</td><td>N.C</td><td>–</td></tr>
<tr><td>15</td><td>AMP-CONT</td><td>O</td><td>MUTE output pin for power amp IC.</td></tr>
<tr><td>16</td><td>SCLK</td><td>O</td><td>SERIAL CLOCK output pin.</td></tr>
<tr><td>17</td><td>SUBQ</td><td>I</td><td>Q DATA input pin.</td></tr>
<tr><td>18</td><td>N.C</td><td>–</td><td>Not used.</td></tr>
<tr><td>19</td><td>SQCK</td><td>O</td><td>CLOCK output pin for reading the Q DATA.</td></tr>
<tr><td>20</td><td>SENS-KEY</td><td>–</td><td>Connected to GND.</td></tr>
<tr><td>21</td><td>N.C</td><td>–</td><td rowspan="3">Not used.</td></tr>
<tr><td>22</td><td>N.C</td><td>–</td></tr>
<tr><td>23</td><td>N.C</td><td>–</td></tr>
<tr><td>24</td><td>PLL CLK</td><td>O</td><td>SERIAL CLOCK output pin for the LCD driver.</td></tr>
<tr><td>25</td><td>ST/MONO</td><td>O</td><td>Output pin for switching control STEREO/MONO.</td></tr>
<tr><td>26</td><td>$\overline{\text{TEL MUTE}}$</td><td>I</td><td>Telephone MUTE input pin.</td></tr>
<tr><td>27</td><td>$\overline{\text{TEST}}$</td><td>I</td><td>When dropped to "L", TEST MODE will be set.</td></tr>
<tr><td>28</td><td>PS SW</td><td>I</td><td>Power select SW input pin.</td></tr>
<tr><td>29</td><td>SCOR ACT</td><td>O</td><td>Activate for SCOR line.</td></tr>
<tr><td>30</td><td>$\overline{\text{APC}}$</td><td>O</td><td>CD pick-up laser power ON/OFF control output.</td></tr>
<tr><td>31</td><td>N.C</td><td>–</td><td>Not used.</td></tr>
<tr><td>32</td><td>$\overline{\text{EMP ON}}$</td><td>O</td><td>Outputs "L" when a DISC which has been pre-emphasized is played back.</td></tr>
<tr><td>33</td><td>VSS</td><td>–</td><td>Connected GND.</td></tr>
<tr><td>34</td><td>PH4 IN</td><td>I</td><td>Not used.</td></tr>
<tr><td>35</td><td>PH2 IN</td><td>I</td><td>Mechanism deck sensor (loading/eject) input pin.</td></tr>
<tr><td>36</td><td>PH1 IN</td><td>I</td><td>Mechanism deck sensor (loading/eject) input pin.</td></tr>
<tr><td>37</td><td>DSW IN</td><td>I</td><td>Mechanism deck sensor input pin.
Detects the completion of the DISC chucking operation.</td></tr>
<tr><td>38</td><td>DK IN</td><td>I</td><td>DK signal input.</td></tr>
<tr><td>39</td><td>SK IN</td><td>I</td><td>SK signal input.</td></tr>
</table>

Pin No.	Pin Name	I / O	Description
40	SD IN	I	SD input pin.
41	$\overline{\text{NOSE SW}}$	I	Front panel Ass'y removal and attaching detection.
42	LAMP ON	O	Not used.
43	ILL ON	O	RESET output pin for UNILINK system. Illumination control output pin.
44	P ON	O	ON/OFF control pin of the power supply.
45	BEEP	O	Alarm drive output pin.
46	$\overline{\text{ACC CHECK}}$	I	ACC line ON/OFF detection.
47	DISC IN /SCOR	I	CD PLAY : SCOR input pin. Others : MD roller open/close detect input.
48	$\overline{\text{KEY ACK}}$	I	Front panel key detecton.
49	SIRCS	I	SIRCS signal input pin.
50	PLL DATA IN	I	SERIAL DATA input pin.
51	IC DATA	O	SERIAL DATA output pin for the LCD driver.
52	IC CLK	O	SERIAL CLOCK output pin for the LCD driver.
53	BU CHECK	I	BATT line ON/OFF detection.
54	Vss	–	Connected to GND.
55	XT1	–	Connected to GND.
56	XT2	–	Not used.
57	Vss	–	Connected to GND.
58	X1	–	The SYSTEM CLOCK (6.0MHz) for system control IC.
59	X2	–	
60	RESET	I	Input pin for system reset.
61	PLL CE	O	CLOCK enable output pin for the PLL IC.
62	N.C	–	Not used.
63	VOL CE	O	CE output pin to the electronic VOL IC.
64	MUTE	O	Audio MUTE output pin.
65	AD ACTIVE	O	VREF control pin of A/D conversion pins.
66	$\overline{\text{LCD INH}}$	O	Pin which outputs INH to the LCD driver IC.
67	LCD CE	O	Pin which outputs CE to the LCD driver IC.
68	COLOR	O	Output pin for switching lighting colors. (AMBER/GREEN)
69	ALARM	–	Connected to GND.
70	SENS	I	SENS input pin from CD servo IC.
71	GFS	I	GFS input pin from CD servo IC.
72	FOK	I	FOK input pin fromt CD servo IC.
73	Vss	–	Connected to GND.
74	S-METER IN	I	S meter voltage detection pin.
75	FUNCTION	I	Connected to GND.
76	MS1	I	MODE select input pin.
77	MS0	I	
78	TEMP-H	I	Temperature detection (High)
79	TEMP-L	I	Temperature detection (Low)
80	KI1	I	Key input pin (A/D conversion input)

- **Semiconductor Lead Layouts**

BA3910B-V3



BU4081BF



CXA1646Q



CXA2515Q



HA13150



LB1638M



LC7216M
MPC1730MR2



LC75821M



MPC1732MR2



RS30E-T



SM5874AM-ET



μPD75518GF-166-3B9



2SD2394-G
2SD2012



CPT-181S-C-TU



DAP202K



DTZ5.6B
DTZ6.8B
MA110
MA8051-M
MA8110-M



DSA3A4



MA4039-M
MA4056-M
MA4060-M
MA4162-M
MA4200-M



MA8051-H
MA8091-M



MA8068H-TX
MA4068-M



CL-155Y/PG-CD



CL-170Y-CD-T



CL-2001R-X-TU



5-2. BLOCK DIAGRAM



5-3. PRINTED WIRING BOARDS – MECHANISM DECK Section –

• See page 16 for Semiconductor Lead Layouts.

• Semiconductor Location

Ref. No.	Location
D801	B-16
D802	C-11
IC1	G-10
IC2	I-8
IC3	H-12
IC4	G-5
IC5	G-9
IC6	G-8
Q1	H-1
Q2	I-5
Q5	G-11



Note:

- ○——— : parts extracted from the component side.
- ● : Through hole.
- ▒▒▒ : Pattern from the side which enables seeing.

(The other layers' patterns are not indicated.)

5-4. SCHEMATIC DIAGRAM – MECHANISM DECK Section – • See page 35 for Waveforms.



• IC Block Diagrams

IC1 CXA1610M



IC2 CXD2515Q



IC3 LB1638M



IC4 SN74HC02ANS



IC5 MPC1732MR2 IC6 MPC1730MR2



Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and ¼ W or less unless otherwise specified.

Note:	Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- ▭▭ : B + Line.
- ▭ : adjustment for repair.
- Power voltage is dc 14.4 V and fed with regulated dc power supply from BATT and ACC terminals.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
  ( ) : CD
- Voltages are taken with a VOM (10 MΩ/V).
  Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.
  Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
  ▱▱ : CD

【MAIN BOARD】



• IC Block Diagrams

IC301 SM5874AM-ET



IC302 CXA1646Q



IC503 BA3910B-V3



IC603 LC7216M



Note:

- All capacitors are in µF unless otherwise noted. pF: µF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and ¼ W or less unless otherwise specified.
- : B + Line.
- : panel designation.
- Power voltage is dc 14.4 V and fed with regulated dc power supply from BATT and ACC terminals.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
  no mark : FM
  ( ) : CD
  < > : AM
- Voltages are taken with a VOM (10 MΩ/V).
  Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.
  Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
  : FM
  : CD

5-6. PRINTED WIRING BOARD – MAIN Section –

• See page 16 for Semiconductor Lead Layouts.

• **Semiconductor Location**

Ref. No.	Location
D1	H-7
D2	H-7
D300	H-10
D301	F-4
D500	B-8
D501	I-1
D502	H-4
D505	G-2
D506	G-2
D507	B-3
D508	B-3
D509	F-2
D510	I-2
D511	C-2
D512	F-3
D513	D-2
D518	G-2
D521	C-4
D523	E-2
D526	B-2
D529	B-1
D531	C-2
D532	C-2
D533	C-2
D550	E-8
D650	D-10 (German)
D655	F-10
D699	G-10
IC301	B-5
IC302	F-6
IC303	I-6
IC304	D-4
IC306	B-9
IC501	D-6
IC502	E-2
IC503	H-1
IC552	F-9
IC603	F-9
IC650	D-9 (German)
Q101	G-10
Q102	G-9
Q201	H-10
Q202	H-9
Q301	H-10
Q500	D-1
Q501	G-3
Q502	E-2
Q503	E-2
Q504	F-4
Q511	D-2
Q513	D-3
Q515	C-3
Q517	D-2
Q519	E-3
Q520	E-1
Q521	E-3
Q522	D-3
Q523	C-8
Q524	F-2
Q550	E-8
Q551	D-3
Q552	C-2
Q553	I-2
Q601	E-10
Q605	D-10
Q650	G-10

Note:

- ○——— : parts extracted from the component side.
- ■ : parts mounted on the conductor side.
- ● : Through hole.
- ▨ : Pattern of the rear side.
- ▩ : Pattern from the side which enables seeing.

【MAIN BOARD】



• **Waveforms**

❶ IC1 ⑮



❺ IC2 ㉕



❷ IC1 ⑬



❻ IC603 ①



❸ IC1 ⑯



❼ IC501 ㉘



❹ IC2 ㊼



❽ IC301 ⑱



5-7. PRINTED WIRING BOARD – DISPLAY Section –

• See page 16 for Semiconductor Lead Layouts.

• Semiconductor Location (US, Canadian, E model)

Ref. No.	Location
D801	J-5
D802	J-7
D803	J-9
D804	J-11
D805	M-4
D806	M-3
D807	J-2
D808	J-3
D809	J-18
D810	J-16
D811	J-14
D812	J-12
D813	L-21
D814	L-19
D815	L-18
D816	N-21
D817	M-20
D818	M-19
D819	N-2
D820	L-2
D821	L-3
D822	L-5
D825	M-10
D826	M-20
D851	J-17
D852	J-17
D853	J-17
D855	M-5
IC801	L-12
IC802	J-19

• Semiconductor Location (AEP, Germany model)

Ref. No.	Location
D801	C-4
D802	C-7
D803	C-9
D804	C-11
D805	F-4
D806	F-3
D807	C-2
D808	C-3
D809	C-18
D810	C-16
D811	C-14
D812	C-12
D813	E-21
D814	E-19
D815	E-18
D816	G-21
D817	F-20
D818	F-19
D819	G-2
D820	E-2
D821	E-3
D822	E-5
D824	G-20
D825	E-10
D826	E-20
D851	C-17
D852	C-17
D853	C-17
D854	G-19
D855	F-5
IC801	E-12
IC802	C-19
Q801	F-19
Q851	G-19

Note:
- ○——: parts extracted from the component side.
- ■: parts mounted on the conductor side.
- ●: Through hole.
- ○: Pattern of the rear side.
- ▒: Pattern from the side which enables seeing.

AEP, German model



US, Canadian, E model



05



Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and ¼ W or less unless otherwise specified.
- ⏚ : B + Line.
- ▭ : panel designation.
- ⏚ Power voltage is dc 14.4 V and fed with regulated dc power supply from BATT and ACC terminals.
- ⏚ Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
  no mark : FM
- ⏚ Voltages are taken with a VOM (10 MΩ/V).
  Voltage variations may be noted due to normal production tolerances.

SECTION 6
EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Color Indication of Appearance Parts
  Example:
  KNOB, BALANCE (WHITE) . . . (RED)
  ↑ ↑
  Parts Color Cabinet's Color
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le neméro spécifié.

(1) GENERAL SECTION



Ref. No.	Part No.	Description	Remark
* 1	A-3252-959-A	PANEL ASSY, FRONT (German)	
* 1	A-3252-960-A	PANEL ASSY, FRONT (AEP)	
* 1	A-3252-961-A	PANEL ASSY, FRONT (US, Canadian, E)	
2	X-3367-725-1	PANEL (SUB) ASSY	
3	X-3366-931-1	LOCK ASSY	
* 4	3-909-315-01	SHEET, INSULATING	
* 5	A-3298-027-A	MAIN BOARD, COMPLETE (German)	
* 5	A-3298-029-A	MAIN BOARD, COMPLETE (E)	
* 5	A-3298-031-A	MAIN BOARD, COMPLETE (AEP)	
* 5	A-3298-033-A	MAIN BOARD, COMPLETE (US, Canadian)	

Ref. No.	Part No.	Description	Remark
6	3-376-464-11	SCREW(+PTT 2.6X6), GROUND POINT	
* 7	X-3367-726-1	COVER ASSY	
8	3-909-332-01	COVER	
* 9	3-909-336-01	BRACKET (MD)	
10	1-765-082-11	CORD (WITH CONNECTOR)	
* 11	3-909-333-11	HEAT SINK	
* 12	3-909-314-01	HEAT SINK	
* 13	3-909-334-01	CHASSIS (MAIN)	
F1	1-533-326-11	FUSE, GLASSS TUBE (3A)	
F2	1-533-331-11	FUSE, GLASSS TUBE (15A)	

(2) FRONT PANEL SECTION



Ref. No.	Part No.	Description	Remark
51	3-908-765-01	BUTTON (MANU)	
52	3-909-321-01	BUTTON (TUNER) (German)	
52	3-909-321-21	BUTTON (AM) (US, Canadian, E)	
52	3-909-321-31	BUTTON (MW/LW) (AEP)	
53	3-909-320-11	BUTTON (FM) (US, Canadian, AEP, E)	
53	3-909-320-41	BUTTON (SDK) (German)	
54	3-909-319-11	BUTTON (CD)	
55	3-909-318-01	BUTTON (+)	
56	3-909-317-01	BUTTON (SEL)	
57	3-909-316-01	BUTTON (-)	
58	3-908-764-01	BUTTON (AMS/SEEK)	
59	3-908-766-01	BUTTON (OFF)	
60	3-909-312-01	FILTER (RAY CATCHER)	
61	3-909-327-01	BUTTON (MUTE)	
62	3-909-326-01	BUTTON (RELEASE)	
63	3-904-193-01	SPRING (RELEASE)	
64	3-909-322-01	SHEET (ILLUMINATOR)	
* 65	A-3295-932-A	DISPLAY BOARD, COMPLETE (AEP, German)	
* 65	A-3298-035-A	DISPLAY BOARD, COMPLETE (US, Canadian, E)	
66	3-909-310-01	PANEL, FRONT BACK	
67	3-911-575-01	SHEET (ELECTROSTATIC)	
68	3-908-763-01	BUTTON (1-6)	
69	3-909-313-01	SHEET (DOOR F)	
* 70	3-909-311-01	PLATE (C), LIGHT GUIDE	
71	3-908-761-01	BUTTON (EJECT)	
72	3-909-329-01	BUTTON (3 GANG)	
73	3-909-823-11	PANEL, FRONT (US, Canadian, AEP, E)	
73	3-909-823-21	PANEL, FRONT (German)	
LCD801	1-810-407-21	DISPLAY PANEL, LIQUID CRYSTAL	

(3) MECHANISM DECK SECTION-1 (MG-205X-130)



Ref. No.	Part No.	Description	Remark
* 101	A-3295-950-A	SERVO BOARD, COMPLETE	
102	3-384-894-01	GEAR (R1)	
103	3-384-900-01	SPRING (PRESS)	
105	3-578-242-11	WASHER	
106	3-384-895-01	GEAR (R2)	
107	3-384-896-01	GEAR (DOWN)	
108	X-3366-858-3	ARM ASSY, FRICTION	
109	3-384-899-01	SPRING (FRICTION)	
110	3-384-892-01	BEARING (ROLLER)	
112	3-701-438-11	WASHER, 2.5	
113	3-323-231-11	ROLLER (T)	
114	3-386-150-01	RING (ROLLER), RETAINING	
115	A-3252-591-A	GEAR ASSY, ROLLER	
* 116	X-3366-852-1	CHASSIS (M) ASSY	
117	3-384-923-01	SHAFT (DAMPER)	
118	3-384-916-01	SPRING (FL)	
119	3-384-914-01	DAMPER	
* 120	3-384-915-11	BRACKET (CP)	
* 121	3-384-918-01	RETAINER (DISC)	

Ref. No.	Part No.	Description	Remark
122	3-384-908-11	ARM, CHUCKING	
* 123	3-384-886-01	GUIDE (DISC)	
124	3-384-888-01	SLIDER (L)	
125	3-384-887-01	LEVER (L)	
126	1-164-401-11	SENSOR FLEXIBLE BOARD	
* 127	A-3222-525-A	SENSOR BOARD, COMPLETE	
* 128	X-3366-854-1	CHASSIS (T) ASSY	
129	3-384-881-02	SPRING (12)	
130	3-384-917-01	SPRING (CH)	
132	X-3366-102-1	SLIDER (R) ASSY	
* 133	X-3365-911-1	CHASSIS (R) ASSY	
134	3-384-889-01	LEVER (R)	
135	3-384-897-01	GEAR (RACK)	
136	3-384-891-01	LEVER (ST)	
137	3-388-331-01	SPRING (T)	
138	3-387-776-01	BELT (L)	
* 139	3-704-132-01	LABEL (K), SELF	
M903	A-3252-580-A	MOTOR (L) ASSY (LOADING)	
S901	1-692-441-11	SWITCH, MICRO (DISC DET)	

(4) MECHANISM DECK SECTION-2 (MG-205X-130)



Ref. No.	Part No.	Description	Remark
151	A-3252-586-A	SHAFT (SL) ASSY	
⚠152	8-848-283-11	DEVICE, OPTICAL KSS-313A	
153	3-384-922-01	GEAR (SL FEED)	
154	3-384-921-01	SPRING (SL FEED)	
* 155	1-650-144-11	MOTOR BOARD	
156	1-646-402-11	MOTOR FLEXIBLE BOARD	

Ref. No.	Part No.	Description	Remark
* 157	X-3365-916-1	CHASSIS (OPT) ASSY (OUTSERT)	
158	X-3366-100-1	BASE (DRIVING) ASSY	
159	3-384-912-01	GEAR (K2)	
160	3-570-615-00	POLY-WASHER (DIA. 1.2)	
161	3-384-913-11	SPRING (THRUST RETAINER)	
M901	X-3367-484-1	MOTOR (SPINDLE) ASSY	
M902	A-3252-585-A	MOTOR (SL) ASSY (SLED)	

Note: The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Note: Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le neméro spécifié.

DISPLAY

SECTION 7
ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
  All resistors are in ohms.
  METAL:Metal-film resistor.
  METAL OXIDE: Metal oxide-film resistor.
  F:nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
  In each case, u:μ, for example:
  uA ..: μA.. uPA..: μPA..
  uPB..: μPB.. uPC..: μPC.. uPD..: μPD..
- CAPACITORS
  uF: μF
- COILS
  uH: μH

When indicating parts by reference number, please include the board.

The components identified by mark ⚠ or dotted line with mark. ⚠ are critical for safety. Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

Ref. No.	Part No.	Description			Remark
*	A-3298-035-A	DISPLAY BOARD, COMPLETE (US, Canadian, E)			
		**********			
*	A-3295-932-A	DISPLAY BOARD, COMPLETE (AEP, German)			
		**********			
*	3-908-754-01	PLATE (LCD), LIGHT GUIDE			
*	3-909-322-01	SHEET (ILLUMINATOR)			
*	3-909-331-01	HOLDER (LCD)			
		< CAPACITOR >			
C801	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C802	1-164-471-11	CERAMIC CHIP	680PF	5%	50V
C830	1-165-128-11	CERAMIC CHIP	0.22uF		16V
		< CONNECTOR >			
CNP801	1-764-423-11	PIN, CONNECTOR 12P			
		< DIODE >			
D801	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D801	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D802	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D802	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D803	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D803	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D804	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D804	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D805	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D805	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D806	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D806	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D807	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D807	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D808	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D808	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D809	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D809	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D810	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D810	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D811	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D811	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D812	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D812	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D813	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D813	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D814	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D814	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D815	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D815	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D816	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D816	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D817	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D817	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D818	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D818	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D819	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D819	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D820	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D820	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D821	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D821	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D822	8-719-033-13	DIODE	CL-170Y-CD-T (US, Canadian, E)		
D822	8-719-987-45	DIODE	CL-155Y/PG-CD (AEP, German)		
D824	8-719-801-78	DIODE	1SS184 (AEP, German)		
D825	8-719-422-43	DIODE	MA8051-H		
D826	8-719-422-43	DIODE	MA8051-H		
D851	8-719-422-97	DIODE	MA8091-M		
D852	8-719-422-97	DIODE	MA8091-M		
D853	8-719-422-97	DIODE	MA8091-M		
D854	8-719-422-97	DIODE	MA8091-M (AEP, German)		
D855	8-719-422-97	DIODE	MA8091-M		
		< IC >			
IC801	8-759-249-93	IC	LC75821W		
IC802	8-749-925-07	IC	RS-30E-T		
		< LIQUID CRYSTAL DISPLAY >			
LCD801	1-810-407-21	DISPLAY PANEL, LIQUID CRYSTAL			

Ref. No.	Part No.	Description			Remark
		< PILOT LAMP >			
PL801	1-517-181-21	LAMP, PILOT			
PL802	1-517-181-21	LAMP, PILOT			
PL850	1-517-181-11	LAMP, PILOT (AEP, German)			
PL851	1-517-181-11	LAMP, PILOT (AEP, German)			
		< TRANSISTOR >			
Q801	8-729-904-66	TRANSISTOR	DTD113EK (AEP, German)		
Q851	8-729-904-66	TRANSISTOR	DTD113EK (AEP, German)		
		< RESISTOR >			
R801	1-218-688-11	METAL CHIP	680	0.50%	1/16W
R802	1-218-845-11	METAL CHIP	820	0.50%	1/16W
R803	1-218-845-11	METAL CHIP	820	0.50%	1/16W
R804	1-216-821-11	METAL CHIP	1K	5%	1/16W
R805	1-216-821-11	METAL CHIP	1K	5%	1/16W
R806	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R807	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R808	1-218-701-11	METAL CHIP	2.4K	0.50%	1/16W
R809	1-218-702-11	METAL CHIP	2.7K	0.50%	1/16W
R810	1-218-706-11	METAL CHIP	3.9K	0.50%	1/16W
R812	1-218-688-11	METAL CHIP	680	0.50%	1/16W
R813	1-218-845-11	METAL CHIP	820	0.50%	1/16W
R814	1-218-845-11	METAL CHIP	820	0.50%	1/16W
R815	1-216-821-11	METAL CHIP	1K	5%	1/16W
R816	1-216-821-11	METAL CHIP	1K	5%	1/16W
R817	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R818	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R819	1-218-701-11	METAL CHIP	2.4K	0.50%	1/16W
R820	1-218-702-11	METAL CHIP	2.7K	0.50%	1/16W
R821	1-218-706-11	METAL CHIP	3.9K	0.50%	1/16W
R822	1-216-817-11	METAL CHIP	470	5%	1/16W
R823	1-218-331-11	METAL GLAZE	51K	5%	1/16W
R830	1-216-027-00	METAL CHIP	120	5%	1/10W
R831	1-216-019-00	METAL CHIP	56	5%	1/10W (AEP, German)
R832	1-216-027-00	METAL CHIP	120	5%	1/10W
R833	1-216-019-00	METAL CHIP	56	5%	1/10W (AEP, German)
R834	1-216-027-00	METAL CHIP	120	5%	1/10W
R835	1-216-019-00	METAL CHIP	56	5%	1/10W (AEP, German)
R836	1-216-033-00	METAL CHIP	220	5%	1/10W
R837	1-216-030-00	METAL CHIP	160	5%	1/10W (AEP, German)
R838	1-216-033-00	METAL CHIP	220	5%	1/10W
R839	1-216-030-00	METAL CHIP	160	5%	1/10W (AEP, German)
R840	1-216-027-00	METAL CHIP	120	5%	1/10W
R841	1-216-019-00	METAL CHIP	56	5%	1/10W (AEP, German)
R842	1-216-821-11	METAL CHIP	1K	5%	1/16W (AEP, German)
R848	1-216-809-11	METAL CHIP	100	5%	1/16W
R849	1-216-821-11	METAL CHIP	1K	5%	1/16W
		< SWITCH >			
SW801	1-572-704-21	SWITCH, KEY BOARD (⏏)			
SW802	1-692-386-21	SWITCH (AM) (US, Canadian)			
SW802	1-692-386-21	SWITCH (MW/LW) (AEP, E)			
SW802	1-692-386-21	SWITCH (TUNER) (German)			
SW803	1-692-386-21	SWITCH (FM) (US, Canadian, AEP, E)			
SW803	1-692-386-21	SWITCH (SDK) (German)			
SW804	1-692-386-21	SWITCH (CD)			
SW805	1-692-386-21	SWITCH (DSPL)			
SW806	1-692-386-21	SWITCH (SENS)			
SW807	1-692-386-21	SWITCH (BTM)			
SW808	1-572-704-21	SWITCH, KEY BOARD (+)			
SW809	1-572-704-21	SWITCH, KEY BOARD (SEL)			
SW810	1-692-386-21	SWITCH (-)			
SW811	1-572-704-21	SWITCH, KEY BOARD (MUTE)			
SW813	1-692-386-21	SWITCH (OFF)			
SW814	1-692-386-21	SWITCH (⏮/- (AMS/SEEK))			
SW815	1-572-704-21	SWITCH, KEY BOARD (+/⏭ (AMS/SEEK))			
SW816	1-572-704-21	SWITCH, KEY BOARD (1/INTOR)			
SW817	1-572-704-21	SWITCH, KEY BOARD (2/REPEAT)			
SW818	1-572-704-21	SWITCH, KEY BOARD (3/SHUF)			
SW819	1-572-704-21	SWITCH, KEY BOARD (4)			
SW820	1-572-704-21	SWITCH, KEY BOARD (5)			
SW821	1-692-386-21	SWITCH (6)			
SW822	1-572-704-21	SWITCH, KEY BOARD (⏪/- (MANU))			
SW823	1-572-704-21	SWITCH, KEY BOARD (+/⏩ (MANU))			
**********					
*	A-3298-027-A	MAIN BOARD, COMPLETE (German)			
		**********			
*	A-3298-029-A	MAIN BOARD, COMPLETE (E)			
		**********			
*	A-3298-031-A	MAIN BOARD, COMPLETE (AEP)			
		**********			
*	A-3298-033-A	MAIN BOARD, COMPLETE (US, Canadian)			
		**********			
	7-682-547-04	SCREW +PTT 3X6 (S)			
	7-621-770-67	SCREW +PTT 2.6X6 (S)			

MAIN

Ref. No.	Part No.	Description			Remark
		< CAPACITOR >			
C001	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C101	1-163-121-00	CERAMIC CHIP	150PF	5%	50V
C102	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C103	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C104	1-163-113-00	CERAMIC CHIP	68PF	5%	50V
C105	1-163-113-00	CERAMIC CHIP	68PF	5%	50V
C108	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C109	1-163-017-00	CERAMIC CHIP	0.0047uF	5%	50V
C111	1-163-019-00	CERAMIC CHIP	0.0068uF	10%	50V
C113	1-163-081-00	CERAMIC CHIP	0.22uF		25V
C114	1-216-295-00	METAL CHIP	0	5%	1/10W
C117	1-126-157-11	ELECT	10uF	20%	16V
C118	1-126-157-11	ELECT	10uF	20%	16V
C119	1-163-141-00	CERAMIC CHIP	0.001uF	5%	50V
C120	1-163-141-00	CERAMIC CHIP	0.001uF	5%	50V
C122	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V (US, Canadian)
C122	1-163-989-11	CERAMIC CHIP	0.033uF	10%	25V (AEP, E, German)
C123	1-164-346-11	CERAMIC CHIP	1uF		16V
C124	1-164-005-11	CERAMIC CHIP	0.47uF		25V
C125	1-164-005-11	CERAMIC CHIP	0.47uF		25V
C126	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C130	1-136-165-00	FILM	0.1uF	5%	50V
C131	1-136-165-00	FILM	0.1uF	5%	50V
C132	1-136-165-00	FILM	0.1uF	5%	50V
C133	1-136-165-00	FILM	0.1uF	5%	50V
C142	1-162-638-11	CERAMIC CHIP	1uF		16V
C143	1-162-638-11	CERAMIC CHIP	1uF		16V
C150	1-126-288-11	ELECT	4.7uF	20%	16V
C201	1-163-121-00	CERAMIC CHIP	150PF	5%	50V
C202	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C203	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C204	1-163-113-00	CERAMIC CHIP	68PF	5%	50V
C205	1-163-113-00	CERAMIC CHIP	68PF	5%	50V
C208	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C209	1-163-017-00	CERAMIC CHIP	0.0047uF	5%	50V
C211	1-163-019-00	CERAMIC CHIP	0.0068uF	10%	50V
C213	1-163-081-00	CERAMIC CHIP	0.22uF		25V
C214	1-216-295-00	METAL CHIP	0	5%	1/10W
C217	1-126-157-11	ELECT	10uF	20%	16V
C218	1-126-157-11	ELECT	10uF	20%	16V
C219	1-163-141-00	CERAMIC CHIP	0.001uF	5%	50V
C220	1-163-141-00	CERAMIC CHIP	0.001uF	5%	50V
C222	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V (US, Canadian)
C222	1-163-989-11	CERAMIC CHIP	0.033uF	10%	25V (AEP, E, German)
C223	1-164-346-11	CERAMIC CHIP	1uF		16V
C224	1-164-005-11	CERAMIC CHIP	0.47uF		25V
C225	1-164-005-11	CERAMIC CHIP	0.47uF		25V
C226	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C230	1-136-165-00	FILM	0.1uF	5%	50V
C231	1-136-165-00	FILM	0.1uF	5%	50V
C232	1-136-165-00	FILM	0.1uF	5%	50V
C233	1-136-165-00	FILM	0.1uF	5%	50V
C242	1-162-638-11	CERAMIC CHIP	1uF		16V
C243	1-162-638-11	CERAMIC CHIP	1uF		16V
C250	1-126-288-11	ELECT	4.7uF	20%	16V
C300	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C301	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C302	1-163-239-11	CERAMIC CHIP	33PF	5%	50V
C303	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C304	1-124-584-00	ELECT	100uF	20%	10V
C305	1-164-346-11	CERAMIC CHIP	1uF		16V
C306	1-124-584-00	ELECT	100uF	20%	10V
C307	1-124-584-00	ELECT	100uF	20%	10V
C308	1-163-141-00	CERAMIC CHIP	0.001uF	5%	50V
C309	1-124-589-11	ELECT	47uF	20%	16V (German)
C310	1-164-222-11	CERAMIC CHIP	0.22uF		25V
C311	1-126-157-11	ELECT	10uF	20%	16V
C312	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C313	1-124-584-00	ELECT	100uF	20%	10V
C314	1-163-109-00	CERAMIC CHIP	47PF	5%	50V
C315	1-126-935-11	ELECT	470uF	20%	16V
C316	1-165-319-11	CERAMIC CHIP	0.1uF		50V
C500	1-163-037-11	CERAMIC CHIP	0.022uF	10%	25V
C502	1-126-768-11	ELECT	2200uF	20%	16V
C504	1-163-229-11	CERAMIC CHIP	12PF	5%	50V
C505	1-163-229-11	CERAMIC CHIP	12PF	5%	50V
C506	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C507	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C508	1-124-584-00	ELECT	100uF	20%	10V
C509	1-124-234-00	ELECT	22uF	20%	16V
C510	1-124-584-00	ELECT	100uF	20%	10V
C511	1-125-701-11	CAP, DOUBLE LAYER			0.047F
C512	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C513	1-163-037-11	CERAMIC CHIP	0.022uF	10%	25V
C514	1-163-037-11	CERAMIC CHIP	0.022uF	10%	25V
C515	1-165-319-11	CERAMIC CHIP	0.1uF		50V (AEP, German)
C516	1-165-319-11	CERAMIC CHIP	0.1uF		50V (AEP, German)

Ref. No.	Part No.	Description			Remark
C517	1-165-319-11	CERAMIC CHIP	0.1uF		50V (AEP, German)
C519	1-163-037-11	CERAMIC CHIP	0.022uF	10%	25V
C522	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C523	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C525	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C526	1-128-057-11	ELECT	330uF	20%	6.3V
C527	1-128-057-11	ELECT	330uF	20%	6.3V
C528	1-127-556-11	ELECT(SOLID)	6.8uF	20%	16V
C531	1-124-234-00	ELECT	22uF	20%	16V
C540	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C541	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C542	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C543	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C550	1-124-589-11	ELECT	47uF	20%	16V
C575	1-163-037-11	CERAMIC CHIP	0.022uF	10%	25V (AEP, German)
C576	1-126-301-11	ELECT	1uF	20%	50V
C600	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C601	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C602	1-163-038-00	CERAMIC CHIP	0.1uF		25V
C604	1-163-097-00	CERAMIC CHIP	15PF	5%	50V
C605	1-163-097-00	CERAMIC CHIP	15PF	5%	50V
C606	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C607	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C608	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C609	1-163-117-00	CERAMIC CHIP	100PF	5%	50V
C611	1-164-222-11	CERAMIC CHIP	0.22uF		25V
C612	1-136-169-00	FILM	0.22uF	5%	50V
C613	1-130-479-00	MYLAR	0.0047uF	5%	50V
C614	1-163-017-00	CERAMIC CHIP	0.0047uF	5%	50V
C617	1-124-589-11	ELECT	47uF	20%	16V
C619	1-124-589-11	ELECT	47uF	20%	16V
C621	1-124-234-00	ELECT	22uF	20%	16V
C626	1-124-589-11	ELECT	47uF	20%	16V
C650	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V (German)
C651	1-136-161-00	FILM	0.047uF	5%	50V (German)
C652	1-136-161-00	FILM	0.047uF	5%	50V (German)
C653	1-163-245-11	CERAMIC CHIP	56PF	5%	50V (German)
C654	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V (German)
C655	1-164-756-11	CERAMIC CHIP	0.0033uF	5%	50V (German)
C656	1-126-288-11	ELECT	4.7uF	20%	16V (German)
C657	1-136-175-00	FILM	0.068uF	5%	50V (German)
C658	1-136-175-00	FILM	0.068uF	5%	50V (German)
C659	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V (German)
C660	1-124-229-00	ELECT	33uF	20%	10V (German)
C661	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V (German)
C662	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V (German)
C663	1-124-589-11	ELECT	47uF	20%	16V (German)
C670	1-163-251-11	CERAMIC CHIP	100PF	5%	50V (German)
C699	1-163-005-11	CERAMIC CHIP	470PF	10%	50V

< CONNECTOR >

CNJ51	1-764-697-31	JACK, PIN 4P (LINE OUT)
CNJ500	1-566-822-11	JACK (EZ-COMMANDER IN)
CNJ502	1-764-808-11	JACK (ANT)
CNP501	1-764-426-11	PLUG, CONNECTOR 15P
CNP502	1-764-422-11	PLUG, CONNECTOR 12P
CNP504	1-764-617-11	PIN, CONNECTOR (PC BOARD) 30P

< DIODE >

D001	8-719-901-33	DIODE	1SS133
D002	8-719-109-53	DIODE	RD2.2ES-B1
D300	8-719-034-22	DIODE	MA4039-M(QZ)
D301	8-719-800-76	DIODE	1SS226
D500	8-719-017-68	DIODE	MA8068H-TX
D501	8-719-945-59	DIODE	DSA3A4
D502	8-719-034-98	DIODE	MA4200-M(QZ)
D505	8-719-034-51	DIODE	MA4068-H(QZ)
D506	8-719-034-90	DIODE	MA4160-M(QZ)
D507	8-719-034-42	DIODE	MA4056-M(QZ)
D508	8-719-977-03	DIODE	DTZ5.6B
D509	8-719-914-44	DIODE	DAP202K
D510	8-719-034-50	DIODE	MA4068-M(QZ)
D511	8-719-977-12	DIODE	DTZ6.8B
D512	8-719-034-42	DIODE	MA4056-M(QZ)
D513	8-719-034-70	DIODE	MA4110-M(QZ)
D518	8-719-034-46	DIODE	MA4062-M(QZ)
D521	8-719-104-34	DIODE	1S2836K
D523	8-719-034-42	DIODE	MA4056-M(QZ)
D526	8-719-034-50	DIODE	MA4068-M(QZ)
D529	8-719-034-50	DIODE	MA4068-M(QZ)

MAIN

Ref. No.	Part No.	Description			Remark
D531	8-719-977-12	DIODE	DTZ6.8B		
D532	8-719-977-12	DIODE	DTZ6.8B		
D533	8-719-420-90	DIODE	MA8051-M		
D550	8-719-801-78	DIODE	1SS184		
D650	8-719-800-76	DIODE	1SS226 (German)		
D655	8-719-404-46	DIODE	MA110 (German)		
D699	8-719-981-59	DIODE	FC805		
		< IC >			
IC301	8-759-196-57	IC	SM5874AM-ET		
IC302	8-752-063-44	IC	CXA1646Q		
IC303	8-759-159-99	IC	HA13150		
IC304	8-759-100-96	IC	uPC4558G2		
IC306	8-759-100-96	IC	uPC4558G2		
IC501	8-759-258-00	IC	uPD75518GF-166-3B9		
IC502	8-759-167-83	IC	PST600EMT-T1		
IC503	8-759-182-76	IC	BA3910B-V3		
IC552	8-759-932-86	IC	BU4081BF		
IC603	8-759-823-81	IC	LC7216M		
IC650	8-759-998-24	IC	TDA1579T (German)		
		< JUMPER RESISTOR >			
JR001	1-216-295-00	METAL CHIP	0	5%	1/10W
		< COIL >			
L301	1-410-973-11	INDUCTOR	22uH		
L303	1-410-973-11	INDUCTOR	22uH		
L501	1-410-973-11	INDUCTOR	22uH		
L602	1-410-973-11	INDUCTOR	22uH		
		< VARIABLE COIL >			
LV650	1-424-036-21	COIL (FILTER)	(German)		
		< TRANSISTOR >			
Q101	8-729-920-21	TRANSISTOR	DTC314TKH04		
Q102	8-729-920-21	TRANSISTOR	DTC314TKH04		
Q201	8-729-920-21	TRANSISTOR	DTC314TKH04		
Q202	8-729-920-21	TRANSISTOR	DTC314TKH04		
Q301	8-729-020-67	TRANSISTOR	XN1A312-TX		
Q500	8-729-209-15	TRANSISTOR	2SD2012		
Q501	8-729-429-92	TRANSISTOR	XN1211		
Q502	8-729-020-67	TRANSISTOR	XN1A312-TX		
Q503	8-729-020-67	TRANSISTOR	XN1A312-TX		
Q504	8-729-422-29	TRANSISTOR	2SD601A-S		
Q511	8-729-106-60	TRANSISTOR	2SB1115A		
Q513	8-729-424-59	TRANSISTOR	UN2212		
Q515	8-729-020-67	TRANSISTOR	XN1A312-TX		
Q517	8-729-424-59	TRANSISTOR	UN2212		
Q519	8-729-424-59	TRANSISTOR	UN2212		
Q520	8-729-019-00	TRANSISTOR	2SD2394-G		
Q521	8-729-422-87	TRANSISTOR	2SB1073-R		
Q522	8-729-422-29	TRANSISTOR	2SD601A-S		
Q523	8-729-424-59	TRANSISTOR	UN2212		
Q524	8-729-402-13	TRANSISTOR	XN1501		
Q550	8-729-421-19	TRANSISTOR	UN2213		
Q551	8-729-422-29	TRANSISTOR	2SD601A-S		
Q552	8-729-216-22	TRANSISTOR	2SA1162-G		
Q553	8-729-424-59	TRANSISTOR	UN2212		
Q601	8-729-021-94	TRANSISTOR	2SK1657-T1B		
Q605	8-729-424-59	TRANSISTOR	UN2212		
Q650	8-729-421-22	TRANSISTOR	UN2211 (German)		
		< RESISTOR >			
R001	1-249-429-11	CARBON	10K	5%	1/4W
R101	1-216-095-00	METAL CHIP	82K	5%	1/10W
R102	1-216-095-00	METAL CHIP	82K	5%	1/10W
R105	1-216-085-00	METAL CHIP	33K	5%	1/10W
R106	1-216-085-00	METAL CHIP	33K	5%	1/10W
R107	1-216-093-00	METAL CHIP	68K	5%	1/10W
R108	1-216-093-00	METAL CHIP	68K	5%	1/10W
R109	1-216-089-00	METAL GLAZE	47K	5%	1/10W
R110	1-216-073-00	METAL CHIP	10K	5%	1/10W
R111	1-216-065-00	METAL CHIP	4.7K	5%	1/10W (US, Canadian)
R111	1-216-077-00	METAL CHIP	15K	5%	1/10W (AEP, E)
R111	1-216-081-00	METAL CHIP	22K	5%	1/10W (German)
R115	1-216-041-00	METAL CHIP	470	5%	1/10W
R116	1-216-041-00	METAL CHIP	470	5%	1/10W
R117	1-216-065-00	METAL CHIP	4.7K	5%	1/10W
R118	1-216-065-00	METAL CHIP	4.7K	5%	1/10W
R124	1-216-134-00	METAL CHIP	2.2	5%	1/8W
R125	1-216-134-00	METAL CHIP	2.2	5%	1/8W
R126	1-216-134-00	METAL CHIP	2.2	5%	1/8W
R127	1-216-134-00	METAL CHIP	2.2	5%	1/8W
R128	1-216-075-00	METAL CHIP	12K	5%	1/10W
R129	1-216-075-00	METAL CHIP	12K	5%	1/10W
R130	1-216-077-00	METAL CHIP	15K	5%	1/10W
R131	1-216-077-00	METAL CHIP	15K	5%	1/10W
R132	1-216-129-00	METAL CHIP	2.2M	5%	1/10W
R133	1-216-129-00	METAL CHIP	2.2M	5%	1/10W
R198	1-216-295-00	METAL CHIP	0	5%	1/10W (US, Canadian)
R201	1-216-095-00	METAL CHIP	82K	5%	1/10W
R202	1-216-095-00	METAL CHIP	82K	5%	1/10W
R205	1-216-085-00	METAL CHIP	33K	5%	1/10W
R206	1-216-085-00	METAL CHIP	33K	5%	1/10W

Ref. No.	Part No.	Description				Remark
R207	1-216-093-00	METAL CHIP	68K	5%	1/10W	
R208	1-216-093-00	METAL CHIP	68K	5%	1/10W	
R209	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R210	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R211	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	
						(US, Canadian)
R211	1-216-077-00	METAL CHIP	15K	5%	1/10W	(AEP, E)
R211	1-216-081-00	METAL CHIP	22K	5%	1/10W	(German)
R215	1-216-041-00	METAL CHIP	470	5%	1/10W	
R216	1-216-041-00	METAL CHIP	470	5%	1/10W	
R217	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	
R218	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	
R224	1-216-134-00	METAL CHIP	2.2	5%	1/8W	
R225	1-216-134-00	METAL CHIP	2.2	5%	1/8W	
R226	1-216-134-00	METAL CHIP	2.2	5%	1/8W	
R227	1-216-134-00	METAL CHIP	2.2	5%	1/8W	
R228	1-216-075-00	METAL CHIP	12K	5%	1/10W	
R229	1-216-075-00	METAL CHIP	12K	5%	1/10W	
R230	1-216-077-00	METAL CHIP	15K	5%	1/10W	
R231	1-216-077-00	METAL CHIP	15K	5%	1/10W	
R232	1-216-129-00	METAL CHIP	2.2M	5%	1/10W	
R233	1-216-129-00	METAL CHIP	2.2M	5%	1/10W	
R298	1-216-295-00	METAL CHIP	0	5%	1/10W	
						(US, Canadian)
R300	1-216-113-00	METAL CHIP	470K	5%	1/10W	
R301	1-216-027-00	METAL CHIP	120	5%	1/10W	
R302	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	(German)
R303	1-216-001-00	METAL CHIP	10	5%	1/10W	
R304	1-216-001-00	METAL CHIP	10	5%	1/10W	
R305	1-216-037-00	METAL CHIP	330	5%	1/10W	
R306	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	(German)
R307	1-216-295-00	METAL CHIP	0	5%	1/10W	
						(US, Canadian, AEP, E)
R310	1-216-025-00	METAL CHIP	100	5%	1/10W	
R311	1-216-025-00	METAL CHIP	100	5%	1/10W	
R312	1-216-025-00	METAL CHIP	100	5%	1/10W	
R313	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R314	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R500	1-216-295-00	METAL CHIP	0	5%	1/10W	
R501	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	
R502	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R503	1-216-070-00	METAL CHIP	7.5K	5%	1/10W	
R505	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	
R506	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R507	1-216-101-00	METAL CHIP	150K	5%	1/10W	
R510	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R511	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R512	1-216-045-00	METAL CHIP	680	5%	1/10W	
R516	1-216-097-00	METAL CHIP	100K	5%	1/10W	

Ref. No.	Part No.	Description				Remark
R517	1-216-097-00	METAL CHIP	100K	5%	1/10W	
R518	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R519	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R520	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R522	1-216-079-00	METAL CHIP	18K	5%	1/10W	
R524	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R525	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R526	1-216-025-00	METAL CHIP	100	5%	1/10W	
R527	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R528	1-216-025-00	METAL CHIP	100	5%	1/10W	
R529	1-216-025-00	METAL CHIP	100	5%	1/10W	
R530	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R531	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R534	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R535	1-216-053-00	METAL CHIP	1.5K	5%	1/10W	
R536	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R541	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R542	1-216-105-00	METAL CHIP	220K	5%	1/10W	
R543	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	
R547	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R548	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R549	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R550	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R551	1-216-097-00	METAL CHIP	100K	5%	1/10W	
R552	1-216-097-00	METAL CHIP	100K	5%	1/10W	
R553	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R554	1-216-085-00	METAL CHIP	33K	5%	1/10W	
R555	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	
R556	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R557	1-216-105-00	METAL CHIP	220K	5%	1/10W	
R558	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R560	1-216-097-00	METAL CHIP	100K	5%	1/10W	(AEP, E)
R561	1-216-097-00	METAL CHIP	100K	5%	1/10W	(German)
R562	1-216-097-00	METAL CHIP	100K	5%	1/10W	(E)
R562	1-216-295-00	METAL CHIP	0	5%	1/10W	
						(US, Canadian, German)
R563	1-216-097-00	METAL CHIP	100K	5%	1/10W	(German)
R563	1-216-295-00	METAL CHIP	0	5%	1/10W	
						(US, Canadian, AEP, E)
R565	1-216-085-00	METAL CHIP	33K	5%	1/10W	
R566	1-216-053-00	METAL CHIP	1.5K	5%	1/10W	
R571	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R572	1-216-105-00	METAL CHIP	220K	5%	1/10W	
R573	1-216-105-00	METAL CHIP	220K	5%	1/10W	
R582	1-216-105-00	METAL CHIP	220K	5%	1/10W	
R583	1-216-097-00	METAL CHIP	100K	5%	1/10W	
R585	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R586	1-216-051-00	METAL CHIP	1.2K	5%	1/10W	
R588	1-216-089-00	METAL GLAZE	47K	5%	1/10W	

MAIN | MOTOR | SENSOR | SENSOR FLEXIBLE

Ref. No.	Part No.	Description				Remark
R589	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R590	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R591	1-216-089-00	METAL GLAZE	47K	5%	1/10W	
R592	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R593	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R594	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R600	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R601	1-216-063-00	METAL CHIP	3.9K	5%	1/10W	
R602	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R603	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R604	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	
R605	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R606	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	
R607	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R608	1-216-049-00	METAL CHIP	1K	5%	1/10W	(US, Canadian)
R608	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	(AEP, E)
R608	1-216-063-00	METAL CHIP	3.9K	5%	1/10W	(German)
R609	1-216-097-00	METAL CHIP	100K	5%	1/10W	
R615	1-216-113-00	METAL CHIP	470K	5%	1/10W	
R621	1-216-059-00	METAL CHIP	2.7K	5%	1/10W	
R622	1-216-059-00	METAL CHIP	2.7K	5%	1/10W	
R624	1-216-073-00	METAL CHIP	10K	5%	1/10W	
R625	1-216-057-00	METAL CHIP	2.2K	5%	1/10W	
R630	1-216-029-00	METAL CHIP	150	5%	1/10W	
R631	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R632	1-216-049-00	METAL CHIP	1K	5%	1/10W	
R650	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	(German)
R651	1-216-061-00	METAL CHIP	3.3K	5%	1/10W	(German)
R652	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	(German)
R653	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	(German)
R654	1-216-116-00	METAL GLAZE	620K	5%	1/10W	(German)
R655	1-216-067-00	METAL CHIP	5.6K	5%	1/10W	(German)
R656	1-216-093-00	METAL CHIP	68K	5%	1/10W	(German)
R657	1-216-089-00	METAL GLAZE	47K	5%	1/10W	(German)
R658	1-216-065-00	METAL CHIP	4.7K	5%	1/10W	(German)
R659	1-216-097-00	METAL CHIP	100K	5%	1/10W	(German)
R660	1-216-117-00	METAL CHIP	680K	5%	1/10W	(German)
R661	1-216-041-00	METAL CHIP	470	5%	1/10W	(German)
R662	1-216-105-00	METAL CHIP	220K	5%	1/10W	(German)
R665	1-216-089-00	METAL GLAZE	47K	5%	1/10W	(German)
R670	1-216-295-00	METAL CHIP	0	5%	1/10W	(US, Canadian, AEP, E)
R999	1-216-295-00	METAL CHIP	0	5%	1/10W	
		< VARIABLE RESISTOR >				
RV601	1-241-930-21	RES, ADJ, METAL GLAZE	100			(German)

Ref. No.	Part No.	Description	Remark
		< SWITCH >	
SW501	1-571-478-11	SWITCH, SLIDE (POWER SELECT)	
SW502	1-572-272-11	SWITCH, SLIDE (CHANNEL SPACE) (E)	
SW503	1-571-532-21	SWITCH, TACTIL (RESET)	
		< THERMISTOR >	
TH501	1-806-715-11	THERMISTOR	
TH502	1-806-715-11	THERMISTOR	
		< VIBRATOR >	
X301	1-579-280-31	VIBRATOR, CRYSTAL (16.9344MHz)	
X501	1-760-096-31	VIBRATOR, CRYSTAL (4.19MHz)	
X601	1-577-126-51	VIBRATOR, CRYSTAL (7.2MHz)	
*	1-650-144-11	MOTOR BOARD	
		**********	
		< CONNECTOR >	
* CNJ303	1-750-160-21	CONNECTOR, FPC 7P	
		< SWITCH >	
S301	1-572-467-21	SWITCH, PUSH (1 KEY) (LIMIT)	
*	A-3222-525-A	SENSOR BOARD, COMPLETE	(Inclde SENSOR FLEXIBLE BOARD)
		**********	
		< DIODE >	
D801	8-719-045-75	DIODE CL-200IR-X-TU	
D802	8-719-045-75	DIODE CL-200IR-X-TU	
		< RESISTOR >	
R801	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
R802	1-216-053-00	METAL CHIP 1.5K 5% 1/10W	
*	1-650-223-11	SENSOR FLEXBLE BOARD	
		**********	
		< SWITCH >	
S901	1-692-441-11	SWITCH, MICROPHONE (DISC DET)	

Ref. No.	Part No.	Description			Remark
*	A-3295-950-A	SERVO BOARD, COMPLETE			
		**********			
		< CAPACITOR >			
C1	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
C2	1-163-235-11	CERAMIC CHIP	22PF	5%	50V
C3	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C4	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C5	1-135-166-21	TANTALUM CHIP	47uF	10%	10V
C7	1-163-005-11	CERAMIC CHIP	470PF	10%	50V
C8	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C9	1-163-005-11	CERAMIC CHIP	470PF	10%	50V
C10	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C11	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C12	1-164-161-11	CERAMIC CHIP	0.0022uF	10%	100V
C13	1-163-011-11	CERAMIC CHIP	0.0015uF	10%	50V
C14	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C15	1-126-191-11	ELECT	0.47uF	20%	50V
C16	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C17	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C18	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
C20	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C21	1-164-346-11	CERAMIC CHIP	1uF		16V
C22	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C23	1-164-346-11	CERAMIC CHIP	1uF		16V
C24	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C25	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C26	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C27	1-135-166-21	TANTALUM CHIP	47uF	10%	10V
C28	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C30	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C31	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C32	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C34	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C35	1-135-166-21	TANTALUM CHIP	47uF	10%	10V
		< CONNECTOR >			
CNJ1	1-565-728-11	CONNECTOR, FPC 17P			
* CNJ2	1-750-159-21	CONNECTOR, FPC 5P			
* CNJ3	1-750-160-21	CONNECTOR, FPC 7P			
CNJ4	1-764-616-21	HOUSING, CONNECTOR (PC BOARD) 30P			
* CNP1	1-580-055-21	PIN, CONNECTOR 2P			
		< IC >			
IC1	8-752-059-30	IC CXA1610M			
IC2	8-752-367-16	IC CXD2515Q			
IC3	8-759-823-87	IC LB1638M			
IC4	8-759-925-72	IC SN74HC02ANS			
IC5	8-759-087-55	IC MPC1732MR2			
IC6	8-759-087-53	IC MPC1730MR2			
		< COIL >			
L1	1-412-058-11	INDUCTOR CHIP	10uH		
L3	1-412-058-11	INDUCTOR CHIP	10uH		
L4	1-412-058-11	INDUCTOR CHIP	10uH		
		< TRANSISTOR >			
Q1	8-729-024-26	PHOTO TRANSISTOR CPT-181S-C-TU			
Q2	8-729-024-26	PHOTO TRANSISTOR CPT-181S-C-TU			
Q5	8-729-141-48	TRANSISTOR 2SB624-BV345			
		< RESISTOR >			
R1	1-216-024-00	METAL GLAZE	91	5%	1/10W
R2	1-216-001-00	METAL CHIP	10	5%	1/10W
R4	1-216-077-00	METAL CHIP	15K	5%	1/10W
R5	1-216-073-00	METAL CHIP	10K	5%	1/10W
R6	1-216-073-00	METAL CHIP	10K	5%	1/10W
R7	1-216-099-00	METAL CHIP	120K	5%	1/10W
R8	1-216-081-00	METAL CHIP	22K	5%	1/10W
R9	1-216-075-00	METAL CHIP	12K	5%	1/10W
R10	1-216-075-00	METAL CHIP	12K	5%	1/10W
R11	1-216-083-00	METAL CHIP	27K	5%	1/10W
R12	1-216-077-00	METAL CHIP	15K	5%	1/10W
R13	1-216-077-00	METAL CHIP	15K	5%	1/10W
R14	1-216-097-00	METAL CHIP	100K	5%	1/10W
R15	1-216-085-00	METAL CHIP	33K	5%	1/10W
R16	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R17	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R18	1-216-073-00	METAL CHIP	10K	5%	1/10W
R19	1-216-121-00	METAL CHIP	1M	5%	1/10W
R20	1-216-097-00	METAL CHIP	100K	5%	1/10W
R21	1-216-073-00	METAL CHIP	10K	5%	1/10W
R22	1-216-033-00	METAL CHIP	220	5%	1/10W
R23	1-216-033-00	METAL CHIP	220	5%	1/10W
R24	1-216-033-00	METAL CHIP	220	5%	1/10W
R25	1-216-073-00	METAL CHIP	10K	5%	1/10W
R27	1-216-295-00	METAL CHIP	0	5%	1/10W
R32	1-216-073-00	METAL CHIP	10K	5%	1/10W
		< VARIABLE RESISTOR >			
RV1	1-238-091-11	RES, ADJ, CERMET	22K		
RV2	1-238-091-11	RES, ADJ, CERMET	22K		
		< SWITCH >			
SW1	1-571-754-31	SWITCH, PUSH (1 KEY) (DISC SET)			

****

Ref. No.	Part No.	Description	Remark
		MISCELLANEOUS	
		**********	
10	1-765-082-11	CORD (WITH CONNECTOR)	
⚠152	8-848-283-11	DEVICE, OPTICAL KSS-313A	
156	1-646-402-11	MOTOR FLEXIBLE BOARD	
F1	1-533-326-11	FUSE, GLASSS TUBE (3A)	
F2	1-533-331-11	FUSE, GLASSS TUBE (15A)	
M901	X-3367-484-A	MOTOR (SPINDLE) ASSY	
M902	A-3252-585-A	MOTOR (SL) ASSY (SLED)	
M903	A-3252-580-A	MOTOR (L) ASSY (LOADING)	
S901	1-692-441-11	SWITCH, MICRO (DISK DET)	

****

HARDWARE LIST

****

#1	7-621-255-25	SCREW +PTT 2X4 (S)	
#2	7-621-770-67	SCREW +B 2.6X6	
#3	7-621-770-XX	SCREW +PTT 2.6X8 (S)	
#4	7-621-771-06	SCREW +B 2X5	
#5	7-621-772-08	SCREW +B 2X3	
#6	7-621-772-10	SCREW +B 2X4	
#7	7-621-772-60	SCREW +B 2X12	
#8	7-621-773-95	SCREW +PTT 2.6X6 (S)	
#9	7-627-552-07	SCREW, PRECISION +P 1.7X2.5	
#10	7-627-552-47	SCREW, PRECISION +P 1.7X4	
#11	7-627-553-18	SCREW, PRECISION +P 2X2	
#12	7-627-553-27	SCREW, PRECISION +P 2X2.5	
#13	7-627-553-37	SCREW, PRECISION +P 2X3	
#14	7-627-553-67	SCREW, PRECISION +P 2X5	
#16	7-685-105-19	SCREW +P 2X8 TYPE2 NON-SLIT	

****

ACCESSORIES & PACKING MATERIALS

****

1-765-082-11 CORD (WITH CONNECTOR)
3-701-626-01 BAG, POLYETHYLENE
3-757-146-21 INSTRUCTION, DEALER
3-758-333-11 MANUAL, INSTRUCTION (ENGLISH, FRENCH, GERMAN, IALIAN) (AEP, German)

3-758-333-21 MANUAL, INSTRUCTION (ENGLISH, FRENCH) (US, Canadian)
3-758-333-41 MANUAL, INSTRUCTION (SPANISH, PORTUGUESE, DUTCH, SWEDISH) (AEP)
3-758-333-51 MANUAL, INSTRUCTION (ENGLISH, SPANISH, CHINESE) (E)

3-758-334-11 MANUAL, INSTRUCTION, INSTALL (ENGLISH, FRENCH, GERMAN, IALIAN) (AEP, German)
3-758-334-21 MANUAL, INSTRUCTION, INSTALL (ENGLISH, FRENCH) (US, Canadian)
3-758-334-41 MANUAL, INSTRUCTION, INSTALL (SPANISH, PORTUGUESE, DUTCH, SWEDISH) (AEP)

3-758-334-51 MANUAL, INSTRUCTION, INSTALL (ENGLISH, SPANISH, CHINESE) (E)
* 3-911-561-01 CUSHION (UPPER)
* 3-911-562-01 CUSHION (LOWER)
* 3-911-775-01 INDIVIDUAL CARTON (CDX-5270:US, Canadian, E)
* 3-911-778-01 INDIVIDUAL CARTON (CDX-5270:AEP)

* 3-911-779-01 INDIVIDUAL CARTON (CDX-5272)
X-3367-795-1 CASE ASSY

****

MOUNTING HARDWARE

****

* 501	X-3366-235-1	FRAME ASSY, FITTING	
502	X-3366-405-1	SCREW ASSY (EXP), FITTING	
503	3-349-410-01	BUSHING	
504	3-388-078-01	KEY	



The components identified by mark ⚠ or dotted line with mark. ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

9-959-298-11

Sony Corporation
Mobile Electronics Group

English
94A0575-1
Printed in Japan
© 1994. 1

Published by Audio Sector Quality Assurance Dept.

CDX-5270/5272

SONY®
SERVICE MANUAL

US Model
Canadian Model
AEP Model
E Model
CDX-5270
German Model
CDX-5272

SUPPLEMENT-1

File this supplement with the service manual.

Subject: • **Mechanism Deck Modification**

(ENG-94008)

The optical pick-up block has been changed from KSS-313A to KSS-410A in the midst of production. According to that the servo board has been modified.
This supplement-1 contains the electrical parts list, the printed wiring boards and the schematic diagram for the new servo board and the exploded views for the new mechanism deck.

SERVO

1. ELECTRICAL PARTS LIST

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
  All resistors are in ohms.
  METAL:Metal-film resistor.
  METAL OXIDE: Metal oxide-film resistor.
  F:nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
  In each case, u:μ, for example:
  uA . . : μA. . uPA. . : μPA. .
  uPB. . : μPB. . uPC. . : μPC. . uPD. . : μPD. .
- CAPACITORS
  uF: μF
- COILS
  uH: μH

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description			Remark
*	A-3298-222-A	SERVO BOARD, COMPLETE			
		**********			
		< CAPACITOR >			
C1	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
C2	1-163-097-00	CERAMIC CHIP	15PF	5%	50V
C3	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C4	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C7	1-163-005-11	CERAMIC CHIP	470PF	10%	50V
C8	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C9	1-163-005-11	CERAMIC CHIP	470PF	10%	50V
C10	1-164-489-11	CERAMIC CHIP	0.22uF	10%	16V
C11	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C12	1-164-161-11	CERAMIC CHIP	0.0022uF	10%	100V
C13	1-163-011-11	CERAMIC CHIP	0.0015uF	10%	50V
C14	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C15	1-126-191-11	ELECT	0.47uF	20%	50V
C16	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C17	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C18	1-126-206-11	ELECT CHIP	100uF	20%	6.3V
C20	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C21	1-164-346-11	CERAMIC CHIP	1uF		16V
C22	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C23	1-164-346-11	CERAMIC CHIP	1uF		16V
C24	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C25	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C26	1-164-232-11	CERAMIC CHIP	0.01uF		50V
C27	1-135-166-21	TANTALUM CHIP	47uF	10%	10V
C28	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C30	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C31	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C32	1-164-492-11	CERAMIC CHIP	0.15uF	10%	16V
C34	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C35	1-135-166-21	TANTALUM CHIP	47uF	10%	10V

Ref. No.	Part No.	Description			Remark
		< CONNECTOR >			
CNJ1	1-766-491-11	CONNECTOR, FPC 17P			
* CNJ2	1-750-159-21	CONNECTOR, FPC 5P			
* CNJ3	1-750-160-21	CONNECTOR, FPC 7P			
CNJ4	1-764-616-21	HOUSING, CONNECTOR(PC BOARD) 30P			
* CNP1	1-580-055-21	PIN, CONNECTOR 2P			
		< IC >			
IC1	8-752-070-74	IC CXA1571M			
IC2	8-752-351-94	IC CXD2515Q			
IC3	8-759-823-87	IC LB1638M			
IC4	8-759-925-72	IC SN74HC02ANS			
IC5	8-759-087-55	IC MPC1732MR2			
IC6	8-759-087-53	IC MPC1730MR2			
		< COIL >			
L1	1-412-058-11	INDUCTOR CHIP	10uH		
L2	1-412-058-11	INDUCTOR CHIP	10uH		
L3	1-412-058-11	INDUCTOR CHIP	10uH		
		< TRANSISTOR >			
Q1	8-729-024-26	PHOTO TRANSISTOR CPT-181S-C-TU			
Q2	8-729-024-26	PHOTO TRANSISTOR CPT-181S-C-TU			
Q5	8-729-141-48	TRANSISTOR 2SB624-BV345			
		< RESISTOR >			
R1	1-216-024-00	METAL GLAZE	91	5%	1/10W
R2	1-216-001-00	METAL CHIP	10	5%	1/10W
R4	1-216-081-00	METAL CHIP	22K	5%	1/10W
R5	1-216-073-00	METAL CHIP	10K	5%	1/10W
R8	1-216-081-00	METAL CHIP	22K	5%	1/10W
R9	1-216-075-00	METAL CHIP	12K	5%	1/10W
R10	1-216-075-00	METAL CHIP	12K	5%	1/10W
R11	1-216-071-00	METAL CHIP	8.2K	5%	1/10W
R12	1-216-077-00	METAL CHIP	15K	5%	1/10W

Ref. No.	Part No.	Description			Remark
R13	1-216-077-00	METAL CHIP	15K	5%	1/10W
R14	1-216-097-00	METAL CHIP	100K	5%	1/10W
R15	1-216-085-00	METAL CHIP	33K	5%	1/10W
R16	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R17	1-216-061-00	METAL CHIP	3.3K	5%	1/10W
R18	1-216-073-00	METAL CHIP	10K	5%	1/10W
R19	1-216-121-00	METAL CHIP	1M	5%	1/10W
R20	1-216-097-00	METAL CHIP	100K	5%	1/10W
R21	1-216-073-00	METAL CHIP	10K	5%	1/10W
R22	1-216-033-00	METAL CHIP	220	5%	1/10W
R23	1-216-033-00	METAL CHIP	220	5%	1/10W
R24	1-216-033-00	METAL CHIP	220	5%	1/10W
R25	1-216-073-00	METAL CHIP	10K	5%	1/10W
R28	1-216-689-11	METAL CHIP	39K	0.50%	1/10W
R29	1-216-689-11	METAL CHIP	39K	0.50%	1/10W
R30	1-218-758-11	METAL CHIP	180K	0.50%	1/10W
R31	1-218-758-11	METAL CHIP	180K	0.50%	1/10W
R32	1-216-073-00	METAL CHIP	10K	5%	1/10W
R36	1-216-129-00	METAL GLAZE	2.2M	5%	1/10W
R37	1-216-129-00	METAL GLAZE	2.2M	5%	1/10W
R38	1-216-101-00	METAL GLAZE	150K	5%	1/10W
		< VARIABLE RESISTOR >			
RV1	1-238-091-11	RES, ADJ, CERMET	22K		
RV2	1-238-091-11	RES, ADJ, CERMET	22K		
		< SWITCH >			
SW1	1-571-754-31	SWITCH, PUSH (1 KEY) (DISC SET)			

2. DIAGRAMS

2-1. PRINTED WIRING BOARD – MECHANISM DECK Section –

• **Semiconductor Location**

Ref. No.	Location
IC1	C-10
IC2	D-9
IC3	D-12
IC4	C-5
IC5	C-9
IC6	B-9
Q1	D-1
Q2	E-6
Q5	C-11



Note:

- ○—— : parts extracted from the component side.
- ● : Through hole.
- ▨ : Pattern from the side which enables seeing.

(The other layers' patterns are not indicated.)

Caution:	
Pattern face side: (SIDE B)	Parts on the pattern face side seen from the pattern face are indicated.
Parts face side: (SIDE A)	Parts on the parts face side seen from the parts face are indicated.

2-2. SCHEMATIC DIAGRAM – MECHANISM DECK Section –



Note:

- All capacitors are in μF unless otherwise noted. pF: μμF 50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and ¼ W or less unless otherwise specified.

Note:	**Note:**
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- B+ : B + Line.
- ▭ : adjustment for repair.
- Power voltage is dc 14.4 V and fed with regulated dc power supply from BATT and ACC terminals.
- Voltages and waveforms are dc with respect to ground under no-signal conditions.
  no mark : CD PLAY
- Voltages are taken with a VOM (10 MΩ/V).
  Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with a oscilloscope.
  Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
  ⇨ : CD

3. EXPLODED VIEWS

NOTE:

- -XX and -X mean standardized parts, so they may have some difference from the original one.
- Items marked " * " are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le neméro spécifié.

(1) MECHANISM DECK SECTION-1 (MG-305X-130)



Ref. No.	Part No.	Description	Remark
* 101	A-3298-222-A	SERVO BOARD, COMPLETE	
102	3-384-894-01	GEAR (R1)	
103	3-384-900-01	SPRING (PRESS)	
105	3-578-242-11	WASHER	
106	3-384-895-01	GEAR (R2)	
107	3-384-896-01	GEAR (DOWN)	
108	X-3366-858-4	ARM ASSY, FRICTION	
109	3-384-899-01	SPRING (FRICTION)	
110	3-384-892-01	BEARING (ROLLER)	
112	3-701-438-11	WASHER, 2.5	
113	3-323-231-11	ROLLER (LOWER)	
114	3-386-150-01	RING (ROLLER), RETAINING	
115	A-3252-591-A	GEAR ASSY, ROLLER	
* 116	X-3366-852-1	CHASSIS (M) ASSY	
117	3-384-923-01	SHAFT (DAMPER)	
118	3-384-916-01	SPRING (FL)	
119	3-384-914-01	DAMPER	
* 120	3-384-915-11	BRACKET (CP)	
* 121	3-384-918-01	RETAINER (DISC)	
122	3-384-908-11	ARM, CHUCKING	
* 123	3-906-923-03	GUIDE (DISC 2)	
124	3-384-888-01	SLIDER (L)	
125	3-384-887-01	LEVER (L)	
126	1-650-223-11	SENSOR FLEXIBLE BOARD	
* 127	A-3222-525-A	SENSOR BOARD, COMPLETE	
* 128	X-3366-854-1	CHASSIS (T) ASSY	
129	3-384-881-02	SPRING (12)	
130	3-384-917-01	SPRING (CH)	
132	X-3366-102-1	SLIDER (R) ASSY	
* 133	X-3366-853-1	CHASSIS (R) ASSY	
134	3-384-889-01	LEVER (R)	
135	3-384-897-01	GEAR (RACK)	
136	3-384-891-01	LEVER (ST)	
137	3-388-331-01	SPRING (T)	
138	3-387-776-01	BELT (L)	
* 139	3-704-132-01	LABEL (K), SELF	
* 149	X-3367-857-1	ARM ASSY, ROLLER	
150	3-918-103-01	SCREW (TOOTH) (+P 2)	
M903	A-3252-580-A	MOTOR (L) ASSY (LOADING)	
S901	1-692-441-11	SWITCH, MICROPHONE (DISC DET)	
#11	7-627-553-18	SCREW, PRECISION +P 2X2	
#12	7-627-553-27	SCREW, PRECISION +P 2X2.5	

(2) MECHANISM DECK SECTION-2 (MG-305X-130)



Ref. No.	Part No.	Description	Remark
151	A-3252-586-A	SHAFT (SL) ASSY	
⚠152	8-848-327-11	DEVICE, OPTICAL KSS-410A	
153	3-384-922-01	GEAR (SL FEED)	
154	3-384-920-01	RETAINER (SL FEED)	
* 155	1-650-144-11	MOTOR BOARD	
156	1-646-402-11	MOTOR FLEXIBLE BOARD	
* 157	X-3366-855-1	CHASSIS (OPT) ASSY (OUTSERT)	
158	X-3366-100-1	BASE (DRIVING) ASSY	
159	3-384-912-01	GEAR (K2)	
160	3-570-615-00	POLY-WASHER (DIA. 1.2)	
161	3-384-913-11	SPRING (THRUST RETAINER)	

Ref. No.	Part No.	Description	Remark
* 162	3-920-313-01	CUSHION (SL)	
163	3-918-062-01	TABLE, DISC	
164	1-652-794-11	PC BOARD, PICKUP FLEXIBLE	
165	3-918-103-01	SCREW (TOOTH) (+P 2)	
M901	X-3367-484-1	MOTOR (SPINDLE) ASSY	
M902	A-3252-585-A	MOTOR (SL) ASSY (SLED)	
#7	7-621-772-60	SCREW +B 2X12	
#9	7-627-552-07	SCREW, PRECISION +P 1.7X2.5	
#10	7-627-552-47	SCREW, PRECISION +P 1.7X4	
#13	7-627-553-37	SCREW, PRECISION +P 2X3	
#14	7-627-553-67	SCREW, PRECISION +P 2X5	

Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note:
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le neméro spécifié.

English
94K0575-1
Printed in Japan

© 1994. 11

Sony Corporation
Mobile Electronics Company
Published by Home A&V Products Div.
Quality Engineering Dept.

9-959-298-81

CDX-5270/5272

SONY

SERVICE MANUAL

US Model
Canadian Model
AEP Model
E model
CDX-5270

German Model
CDX-5272

CORRECTION-1

Correct your service manual as shown below.

____ (Under line) : indicates corrected portion.

SUPPLEMENT-1 (9-959-298-81)

Page	INCORRECT			CORRECT		
	Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
11	*149	X-3367-857-1	ARM ASSY, ROLLER	*149	X-3366-857-1	ARM ASSY, ROLLER

(SPM-95042)

9-959-298-91

Sony Corporation
Mobile Electronics Company

English
95I0472-1
Printed in Japan
©1995.9
Published by Home A&V Products Div.
Quality Engineering Dept.

CDX-5270/5272

SONY

SERVICE MANUAL

US Model
Canadian Model
AEP Model
E Model
CDX-5270
German Model
CDX-5272

CORRECTION-2

Correct your service manual as shown below.

☛ : indicates corrected portion.

<table>
<tr><th>Page</th><th>INCORRECT</th><th>CORRECT</th></tr>
<tr><td>22</td><td>【SENSOR FLEXIBLE BOARD】
 
</td><td>【SENSOR FLEXIBLE BOARD】
 
</td></tr>
<tr><td>44</td><td>Ref. No. Part No. Description
126 1-164-401-11 SENSOR FLEXIBLE BOARD</td><td>Part No. Description
1-646-401-11 SENSOR FLEXIBLE BOARD ☛</td></tr>
<tr><td>52</td><td>Ref. No. Part No. Description
* 1-650-223-11 SENSOR FLEXIBLE BOARD
**********</td><td>Part No. Description
1-646-401-11 SENSOR FLEXIBLE BOARD ☛
**********</td></tr>
</table>

• Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

(SPM-95057)

9-959-298-92

Sony Corporation
Mobile Electronics Company

English
95K050472-1
Printed in Japan

© 1995. 11

Published by Home A&V Products Div.
Quality Engineering Dept.